

Leica Builder Series User Manual

Version 1.0
English

- when it has to be **right**

Leica
Geosystems

Introduction

Purchase

Congratulations on the purchase of a Builder series instrument.



This manual contains important safety directions as well as instructions for setting up the product and operating it. Refer to "17 Safety Directions" for further information.



Read carefully through the User Manual before you switch on the product.

Product identification





The type and the serial number of your product are indicated on the type plate. Enter the type and serial number in your manual and always refer to this information when you need to contact your agency or Leica Geosystems authorized service workshop.

Type: _____

Serial No.: _____

Symbols

The symbols used in this manual have the following meanings:

Type	Description
 Danger	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 Warning	Indicates a potentially hazardous situation or an unintended use which, if not avoided, could result in death or serious injury.
 Caution	Indicates a potentially hazardous situation or an unintended use which, if not avoided, may result in minor or moderate injury and/or appreciable material, financial and environmental damage.
	Important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

Trademarks

- Windows is a registered trademark of Microsoft Corporation
 - Bluetooth is a registered trademark of Bluetooth SIG, Inc.
- All other trademarks are the property of their respective owners.

Table of Contents

In this manual	Chapter	Page
	1 How to Use this Manual	12
	2 Technical Terms and Abbreviations	14
	3 Description of the System	20
	3.1 Instrument Models	20
	3.2 Container Contents	21
	3.3 Instrument Components	23
	3.4 Power Supply	26
	3.5 Software Concept	27
	4 User Interface	30
	4.1 Keyboard	30
	4.2 Screen	34
	4.3 Tab Bar	36
	4.4 Icons	37
	4.5 Symbols	38

5	Operation	40
5.1	Selection of Language	40
5.2	Instrument Setup	42
5.3	Instrument Battery	49
5.4	USB Memory Stick	52
5.5	Distance Measurement	54
5.5.1	General	54
5.5.2	Measurement with Red Dot	55
5.5.3	Measurement with Prism	57
5.6	CPR105 Flat Prism	58
5.7	CPR111 Builder Prism, True-Zero Offset	59
6	Configuration Mode	60
6.1	Overview	60
6.2	Accessing	61
6.3	Communication Parameters	72
6.4	How to Make a Setting	76
6.5	Pin Assignment	77

7	Theodolite Mode	78
7.1	Overview	78
7.2	Accessing	79
7.3	How to Set Horizontal Angle to 0.000	81
7.4	How to Set Any Horizontal Angle	82
7.5	Quick Setting of Horizontal Angle and Vertical Angle Direction Measurement	83
8	Program Mode, for Builder 200 or higher	84
8.1	Overview	84
8.2	Accessing	85
8.3	Pointsearch	86
8.4	Measure and Record	88

9	Station Setup, for Builder 200 or higher	92
9.1	Overview	92
9.2	Setup Option 1: Establish Control Line	94
9.2.1	General	94
9.2.2	Establish Control Line - Over 1 st Point	95
9.2.3	Establish Control Line - Anywhere	96
9.3	Setup Option 2: Establish Coordinates	99
9.3.1	General	99
9.3.2	Establish Coordinates - Over Known Point	100
9.3.3	Establish Coordinates - Anywhere	102
9.4	Setup Option 3: Establish Height	104
9.4.1	General	104
9.4.2	Height Transfer	105

10	Application Programs, for Builder 200 or higher	106
10.1	Overview	106
10.2	Layout	108
10.3	As Built	111
10.4	Angle & Distance	114
10.5	Tie Distance	116
10.6	Area and Stockpile Volumes	119
	10.6.1 Area Application	120
	10.6.2 Stockpile Volumes Application	123
10.7	Hidden Point (optional)	124
10.8	COGO (optional)	128
10.9	Layout Line/Arc/Spiral (optional)	137
10.10	Measure & Descriptor	143
11	Data Management Mode, for Builder 300 or higher	146
11.1	Overview	146
11.2	Accessing	147
11.3	Jobs	149
11.4	Fixpoints	151
11.5	Measurements	153
11.6	Result	155
11.7	Data Transfer	156
	11.7.1 USB Memory Stick - Import / Export	156

12 EDM Settings	160
12.1 EDM	160
12.2 PPM	163
13 System Info and Instrument Protection	168
13.1 System Info	168
13.2 Instrument Protection (PIN)	171
13.3 Software Upload	174
13.4 Maintenance Key Upload	176
14 Check & Adjust	178
14.1 Overview	178
14.2 Preparation	180
14.3 Combined Adjustment of Hz Collimation (c), Vertical Index (i) and Compensator Index (l, t) Errors	181
14.4 Adjustment of the Circular Level	186
14.5 Adjustment of the Laser Plummet	188
14.6 Service of the Tripod	191
14.7 Inspection of the Red Laser Beam, for Builder 200 or higher	192
14.8 Adjustment of the Vertical Line of the Reticule, for Builder 100	194

15	Care and Transport	196
15.1	Transport	196
15.2	Storage	197
15.3	Cleaning and Drying	199
16	Construction Data Manager	202
16.1	Overview	202
16.2	Installation	202
16.3	Connection	203
16.4	Online help	205
17	Safety Directions	206
17.1	General	206
17.2	Intended Use	207
17.3	Limits of Use	209
17.4	Responsibilities	210
17.5	Hazards of Use	211
17.6	Laser Classification	217
17.6.1	Integrated Distancer, Measurements with Red Dot (for Builder 200 or higher)	218
17.6.2	Integrated Distancer, Measurements with Prism (only Builder 400 and 500)	222
17.6.3	Laser Plummet	224

17.7	Electromagnetic Compatibility EMC	228
17.8	FCC Statement, Applicable in U.S.	231
18	Technical Data	234
<hr/>		
18.1	Angle Measurement	234
18.2	Distance Measurement	235
18.3	General Technical Data of the Instrument	239
18.4	Conformity to National Regulations	246
	18.4.1 Products without Communication side cover	246
	18.4.2 Products with Communication side cover	247
19	International Limited Warranty, Software License Agreement	248
<hr/>		
	Index	250
<hr/>		

1 How to Use this Manual



It is recommended to set-up the instrument while reading through this manual.

Index

The index is at the back of the manual.



Keys, fields and options on the screens which are considered as self-explanatory are not explained.

Validity of this manual

This manual applies to all Builder instruments. Differences between the various models are marked and described.

Available documentation



Name of documentation	Description
Builder User Manual	All instructions required in order to operate the instrument to a basic level are contained in this User Manual. Provides an overview of the instrument together with technical data and safety directions.
Builder How-to Guide	Describes how to solve several construction tasks with the onboard application programs step-by-step. It is intended as a reference field guide.

**Format of the
documentation**

The Builder CD contains the entire documentation in electronic format. It is also available in printed form.

2 Technical Terms and Abbreviations

Terminology



	Term	Description
a)	Line of sight / collimation axis	Telescope axis = line from the reticle to the centre of the objective.
b)	Standing axis	Vertical rotation axis of the instrument.
c)	Tilting axis	Horizontal rotation axis of the telescope.
d)	Vertical angle / zenith angle	
e)	Vertical circle	With coded circular division for reading the vertical angle.
f)	Horizontal angle	
g)	Horizontal circle	With coded circular division for reading the horizontal angle.

**Plumb line /
Compensator**




Direction of gravity. The compensator defines the plumb line within the instrument

**Standing axis incli-
nation**




Angle between plumb line and standing axis. Standing axis tilt is not an instrument error and is not eliminated by measuring in both faces. Any possible influence it may have on the horizontal direction resp. vertical angle is eliminated by the dual axis compensator.

Zenith




Point on the plumb line above the observer.




Reticle



Glass plate within the telescope with reticle.

Explanation of displayed data



Abbreviation	Description
	Indicated meteorological corrected slope distance between instrument tilting axis and centre of prism/laser dot.
	Indicated meteorological corrected horizontal distance.
	Height difference between station and target point.
hr	Reflector height above ground.
hi	Instrument height above ground.
E_0	Easting of Station.
N_0	Northing of Station.
H_0	Height of Station.
E	Easting of target point.
N	Northing of target point.
H	Height of target point.

3 Description of the System

3.1 Instrument Models

Instrument models

Model	Description
Builder 100	Electronic theodolite.
Builder 200	Electronic theodolite with distance measurement capability, RS232 interface and construction software.
Builder 300	Same as Builder 200, additionally with internal memory to store and manage data, a USB mini and host interface and an extended application menu.
Builder 400	Same as Builder 300, additionally with 10-digits keypad, LED that shows the EDM mode used and an extended application menu.
Builder 500	Same as Builder 400, additionally with Bluetooth and full EDM ranges.



Builder 100, 200 and 300 are available as 6" or 9".

Builder 400 is available as 5" and 9".


Builder 500 is available as 3", 5", 9" and 5" Arctic.

The angle accuracy is represented by the last digit of the instrument name. For example, Builder 505 is the 5" variant of the 500 series.

3.2

Container Contents


Container contents, part 1 of 2



- a) Builder instrument with supplied tribrach
- b) GEV189 USB data transfer cable*
- c) GLI115 clip-on bubble (for Builder 200 and 300)
- d) GHT196 holder for height meter*
- e) CPR105 Flat prism (for Builder 200 and 300)
- f) GHM007 height meter*
- g) Protective cover / lens hood
- h) GEV223 data cable USB to mini USB (for Builder 300 or higher)
- i) CPR111 Builder prism, true-zero offset (for Builder 400 or 500)

* Optional

Container contents, part 2 of 2



- j) Adjustment tools
 - k) GFZ3 diagonal eyepiece*
 - l) GEB211 batteries
 - m) GKL211 battery charger
 - n) GAD105 Flat or mini prism adapter*
 - o) MS1 Leica industrial grade USB memory stick (for Builder 300 or higher)
 - p) GEB221 battery*
 - q) Tip for mini prism pole
 - r) Counterweight for diagonal eyepiece*
 - s) User Manual, CD-ROM
 - t) GLS115 mini prism pole
- * Optional




The content depends on the chosen Builder model.

3.3

Instrument Components


Instrument components, part 1 of 2



- a) Compartment for USB memory stick and USB cable ports (for Builder 300 or higher)
- b) Bluetooth antenna (only Builder 500)
- c) Alignment sight
- d) Detachable carrying handle with mounting screw
- e) Telescope (with integrated Distance Meter for Builder 200 or higher)
- f) Vertical drive
- g) On/Off key
- h) Switch key
- i) Horizontal drive
- j) Second keyboard*
(Keyboard depends on model. Refer to chapter "4.1 Keyboard".)

* Optional


Instrument components, part 2 of 2



- k) Telescope focusing ring
- l) Eyepiece; focusing graticule
- m) Battery holder for GEB211/GEB221
- n) Serial interface RS232 (for Builder 200 or higher)
- o) Footscrew
- p) Display
- q) Keyboard (Keyboard depends on model. Refer to chapter "4.1 Keyboard".)

Communication side cover

The Communication side cover with USB is standard for Builder 300 or higher and in case of the Builder 500 series additionally with Bluetooth.



- a) Bluetooth antenna (only Builder 500)
- b) Compartment lid
- c) USB memory stick cap storage
- d) USB host port
- e) USB device port

3.4 Power Supply

Instrument

Power for the instrument can be supplied either internally or externally.



Internal battery

- One GEB211 battery,
 - or one GEB221 battery
- fitted into the battery compartment.

External battery

- One GEB171 battery
- connected via cable.

Batteries



a) GEB221

b) GEB211



Use the Leica Geosystems batteries, chargers and accessories or accessories recommended by Leica Geosystems to ensure the correct functionality of the instrument.



3.5


Software Concept

Description

All instrument types use the same software concept. The software has different modes depending on the instrument type.

Software Concept

Model	Screen	Available Modes
Builder 100	 <p>CONFIG THEO 04:07 Hz ←: 48.0000 g V ↑: 60.0000 g Hz HOLD Hz = 0 LEVEL</p>	<ul style="list-style-type: none">• Configuration Mode• Theodolite Mode
Builder 200	 <p>CONFIG THEO PROG 04:07 Hz ←: 48.0000 g V ↑: 60.0000 g Hz HOLD Hz = 0 LEVEL</p>	<ul style="list-style-type: none">• Configuration Mode• Theodolite Mode• Programs Mode


Model	Screen	Available Modes
Builder 300, 400 and 500	 <p>The screenshot shows a menu with four options: CONFIG, THEO (highlighted), PROG, and DATA. Below the menu, the time 04:07 is displayed. Two data rows are shown: Hz with a left arrow icon, value 48.0000 g, and a battery icon; and V with an up arrow icon, value 60.0000 g, and an envelope icon. At the bottom, there are three buttons: Hz HOLD, Hz = 0, and LEVEL.</p>	<ul style="list-style-type: none">• Configuration Mode• Theodolite Mode• Programs Mode• Data Management Mode

4 User Interface

4.1 Keyboard


Keyboard

Builder 100, 200 and 300



- a) Page key
- b) Navigation keys
- c) ESC
- d) Light
- e) Function keys






Builder 400 and 500






- a) Page key
- b) 10-digits keypad
- c) Navigation keys
- d) ESC
- e) Light
- f) EDM key
- g) LED
- h) Function keys

Keys



All Builder models:

Key	Description
	Changes tab in the tab bar.
	<ul style="list-style-type: none">• Move the focus on the screen• Start the edit mode for edit fields• Control the input bar in edit and input mode
	<ul style="list-style-type: none">• Leaves the current menu or dialog without storing changes made.• If THEO mode is active: press for approximately 5 seconds to access System Info.
	Turns the display light incl. reticle illumination on and off.
	Correspond to the three softkeys that appear on the bottom of the screen when the screen is activated.

Only Builder 400 and 500:

Key/LED	Description
	<ul style="list-style-type: none">• Press button short: to access the EDM settings• Press button long: to toggle between red dot and prism
	Alphanumeric keys
	<ul style="list-style-type: none">• LED white: EDM type is prism• LED red: EDM type is red dot• LED flashes once if the EDM setting has changed by toggling or when a measurement is taken• LED blinks if EDM measures in tracking-mode

Sidecover keys

Key	Description
	On / Off key. Switches the instrument on or off.
	Switch key. Switch Key 1 is the top end, Switch Key 2 is the lower end of the Switch key.

Switch key functionality

Builder model	Switch key 1	Switch key 2
100 series	Sector beep on/off	-
200 series	Laser pointer on/off	-
300 series	Laser pointer on/off	-
400 series	EDM tracking on/off	Switch between Measure/Record, All in 1 and Measure
500 series	Laser pointer on/off	Switch between Measure/Record, All in 1 and Measure


4.2

Screen



All shown screens are examples. It is possible that local software versions are different to the basic version.

Screen



- a) Tab bar
- b) Time
- c) Icons
- d) Screen area
- e) Softkeys


Description

Element	Description
Tab bar	The current active tab is shown black.
Time	Shows the current time provided that the setting is made in the configurations.
Icons	Shows the current status information of the instrument. Refer to "4.4 Icons".
Screen area	The working area of the screen.
Softkeys	Commands can be executed using the function keys. The commands assigned to the softkeys are screen dependent.

4.3 Tab Bar

Tab bar

In the tab bar the current active software mode is shown black.



Tab	Mode
CONFIG	Configuration Mode
THEO	Theodolite Mode
PROG	Program Mode (for Builder 200 or higher)
MODE	Data Management Mode (for Builder 300 or higher)



The availability of the tabs depends on the instrument model.

4.4


Icons

Description

The icons provide information related to basic instrument functions.



Battery

The status and source of the battery is displayed.

Icon	Description
	Battery capacity The battery symbol indicates the level of the remaining battery capacity, 75% full shown in the example.

Compensator

Compensator on or off is displayed.



Icon	Description
	Compensator is turned on.
	Compensator is turned off.

4.5

Symbols



Horizontal angle

The direction of the horizontal angle is displayed.




Symbol	Description
	Indicates that horizontal angle is set to right side angle measurement (clockwise).
	Indicates that horizontal angle is set to left side angle measurement (anticlockwise).

Vertical angle



The "0"-Orientation of the vertical angle is displayed.

Symbol	Description
	Indicates that the "0"-orientation of the vertical angle is selected to the zenith.
	Indicates that the "0"-orientation of the vertical angle is selected to the horizon.
%	Indicates that the vertical angle is shown in percentage.

Distance

Symbol	Description
	This symbol indicates the horizontal distance .
	This symbol indicates the height difference .
	This symbol indicates the slope distance .

Triangles

Symbol	Description
	Double triangles on the right indicate a choice field .
	A single triangle on the right indicates a choice list .

5 Operation

5.1 Selection of Language

Description

After switching on the instrument the user is able to choose his preferred language.



The dialog to choose the language is only shown if two or more languages are loaded onto the instrument and **<Lang.Dialog: On>** is set in Configuration mode or on System Info dialog.

Loading/Changing languages

Instrument model	To load an additional language or to change the existing language(s),
Builder 300 or higher	connect the instrument to Construction Data Manager Version 6.0 or higher via the serial interface or USB cable and load using Tools - Software Upload . Alternatively store the Builder Firmware Language Files into the System folder on the USB memory stick, insert the stick into the instrument and load the languages via the upload tool within System Info (refer to chapter "13.3 Software Upload").

Instrument model	To load an additional language or to change the existing language(s),
Builder 200	connect the instrument to Construction Data Manager Version 6.0 or higher via the serial interface and load using Tools - Software Upload .
Builder 100	contact your Leica Geosystems authorized service workshop.

5.2 Instrument Setup

Description


This topic describes an instrument setup over a marked ground point using the laser plummet. It is always possible to set up the instrument without the need for a marked ground point.



Important features:


- It is always recommended to shield the instrument from direct sunlight and avoid uneven temperatures around the instrument.
- The laser plummet described in this topic is built into the vertical axis of the instrument. It projects a red spot onto the ground, making it appreciably easier to centre the instrument.
- The laser plummet cannot be used in conjunction with a tribrach equipped with an optical plummet.

Tripod




Builder_0866

When setting up the tripod pay attention to ensuring a horizontal position of the tripod plate. Slight corrections of inclination can be made with the foot screws of the tribrach. Larger corrections must be done with the tripod legs.



Loosen the clamping screws on the tripod legs, pull out to the required length and tighten the clamps.



- a In order to guarantee a firm foothold sufficiently press the tripod legs into the ground.
- b When pressing the legs into the ground note that the force must be applied along the legs.




Careful handling of tripod.

- Check all screws and bolts for correct fit.
- During transport always use the cover supplied.
- Use the tripod only for surveying tasks.

Setup step-by-step



1. Extend the tripod legs to allow for a comfortable working posture. Position the tripod over the marked ground point, centring it as well as possible.
2. Fasten the tribrach and instrument onto the tripod.
3. Turn on the instrument by pressing the  key.


The electronic level and laser plummet are activated automatically after switching on the instrument, if compensator is set to on.

4. Move the tripod legs (1) and use the tribrach footscrews (6) to centre the plummet (4) over the ground point.

5. Adjust the tripod legs (5) to level the circular level (7).
 6. By using the electronic level turn the tribrach footscrews (6) to precisely level the instrument.
Refer to "Levelling up with the electronic level step-by-step" for more information.
 7. Centre the instrument precisely over the ground point (4) by shifting the tribrach on the tripod plate (2).
 8. Repeat steps 6. and 7. until the required accuracy is achieved.
-

Levelling up with the electronic level step-by-step

The electronic level can be used to precisely level up the instrument using the footscrews of the tribrach.

1. Turn on the instrument by pressing the  key.

The electronic level and laser plummet are activated automatically after switching on the instrument, if compensator is set to on.


2. Centre the circular level approximately by turning the footscrews of the tribrach.




The bubble of the electronic level and the arrows for the rotating direction of the footscrews only appear if the instrument tilt is inside a certain levelling range.

3. Turn the instrument until it is parallel to two footscrews.


4. Centre the electronic level of this axis by turning the two footscrews. Arrows show the direction for rotating the footscrews. When the electronic level is centred the arrows are replaced by checkmarks.



5. Centre the electronic level for the second axis by turning the last footscrew. An arrow shows the direction for rotating the footscrew. When the electronic level is centred the arrow is replaced by a checkmark.




When the electronic level is centred and three checkmarks are shown, the instrument has been perfectly leveled up.



6. Accept with **OK**.


Changing the intensity of the laser plummet

External influences and the surface conditions may require the adjustment of the intensity of the laser plummet.


1. Turn on the instrument by pressing the  key.


The electronic level and laser plummet are activated automatically after switching on the instrument, if compensator is set to on.

2. Adjust the intensity of the laser plummet by


pressing .

The laser can be adjusted in 25% steps as required.



Positioning over pipes or holes


Under some circumstances the laser dot is not visible, for example over pipes. In this case, the laser dot can be made visible by using a transparent plate so that the laser dot can be easily aligned to the center of the pipe.

Centring with the optional shifting tribrach step-by-step



If the instrument is equipped with the optional shifting tribrach it can be aligned to the ground point by slight shifting.

1. Loosen screw.
2. Shift instrument.
3. Fix instrument by turning screw.


5.3

Instrument Battery

Change instrument battery step-by-step



1. Open the battery compartment.
2. Remove the battery holder.
3. Remove the battery from the battery holder.



4. Insert the new battery into the battery holder, ensuring that the contacts are facing outward. The battery should click into position.
5. Insert the battery holder back into the battery compartment.
6. Turn the knob to lock the battery holder in place.



The polarity of the battery is displayed inside the battery housing.



Charging / first-time use

- **For all batteries**

- The battery must be charged prior to using it for the first time because it is delivered with an energy content as low as possible.
- The permissible temperature range for charging is between 0°C to +40°C/+32°F to +104°F. For optimal charging we recommend charging the batteries at a low ambient temperature of +10°C to +20°C/+50°F to +68°F if possible.
- It is normal for the battery to become warm during charging. Using the chargers recommended by Leica Geosystems, it is not possible to charge the battery if the temperature is too high.

- **For Li-Ion batteries**

- For new batteries or batteries that have been stored for a long time (> three months), it is effectual to make only one charge/discharge cycles.
- For Li-Ion batteries, a single discharging and charging cycle is sufficient. We recommend carrying out the process when the battery capacity indicated on the charger or on a Leica Geosystems product deviates significantly from the actual battery capacity available.

- **For NiMH batteries**

- For new batteries or batteries that have been stored for a long time (> three months), it is effectual to make 3 - 5 charge/discharge cycles.

**Operation / discharging**

- The batteries can be operated from -20°C to +50°C/-4°F to +122°F.
- Low operating temperatures reduce the capacity that can be drawn; very high operating temperatures reduce the service life of the battery.

Inserting and removing the batteries


Batteries not recommended by Leica Geosystems may be damaged if charged or discharged. They may burn and explode.

Precautions:


Only charge and discharge batteries recommended by Leica Geosystems.

5.4 USB Memory Stick

Insert a USB memory stick step-by-step



1. Open the compartment lid on the Communication side cover.
2. The USB host port is located underneath the top edge of the compartment.



3. Insert the USB memory stick into the USB host port.
4. The cap of a Leica industrial grade USB memory stick can be stored on the underside of the compartment lid.
5. Close the compartment lid and turn the knob to lock the compartment closed.



Always return to the **MAIN MENU** before removing the USB memory stick.



Whilst other USB memory sticks may be used, Leica Geosystems recommends Leica industrial grade USB memory sticks and cannot be held responsible for data loss or any other error that may occur when using a non-Leica USB memory stick.



- Keep the USB memory stick dry.
- Use it only within the specified temperature range, -40°C to +85°C (-40°F to +185°F).
- Protect the USB memory stick from direct impacts.

Failure to follow these instructions could result in data loss and/or permanent damage to the USB memory stick.

5.5 Distance Measurement

5.5.1 General

Description

A laser distancer (EDM) is incorporated into the instruments (Builder 200 or higher) of the Builder series. In all these versions, the distance can be determined by using a visible red laser beam which emerges coaxially from the telescope objective.

There are two EDM types:

- Measurements with red dot (any surface or CPR105 Flat prism)
- Measurements with prism (CPR111 Builder prism, true-zero offset)




Available EDM types depend on the model.

In the standard version of the Builder 400 and 500, the maximum distance measurement range is 500 m. Please refer to "12.1 EDM" on how to upgrade the measurement range.

5.5.2

Measurement with Red Dot

Description



- When measurements are being made using the red laser EDM, the results may be influenced by objects passing between the EDM and the intended target surface. This occurs because red dot measurements are made to the first surface returning sufficient energy to allow the measurement to take place. For example, if the intended target surface is the surface of a road, but a vehicle passes between the EDM and the target surface as MEASURE or M&R is pressed, the measurement may be made to the side of the vehicle. The result is the distance to the vehicle, not to the road surface.
- When a distance measurement is triggered, the EDM measures to the object which is in the beam path at that moment. If a temporary obstruction, for

example a passing vehicle, heavy rain, fog or snow is between the instrument and the point to be measured, the EDM may measure to the obstruction.

- Be sure that the laser beam is not reflected by anything close to the line of sight, for example highly reflective objects.
- When measuring longer distances, any divergence of the red laser beam from the line of sight might lead to less accurate measurements. This is because the laser beam might not be reflected from the point at which the crosshairs are pointing. Therefore, it is recommended that the visible laser beam is aligned with the center of the target. Refer to "14 Check & Adjust" for more information on how to check the alignment.
- Do not measure with two instruments to the same target simultaneously.



Guidelines for correct results / Distance measurement:

During to laser safety regulations and measuring accuracy, using the Long Range Reflectorless EDM is only allowed to prisms that are more than 1000 m (3300 ft) away.

5.5.3

Measurement with Prism

Description


- Accurate measurements to prisms should be made with the standard program (EDM type: prism).
 - Measurements to strongly reflecting targets such as to traffic lights in reflector EDM mode without prism should be avoided. The measured distances may be wrong or inaccurate.
 - Very short distances may be measured reflectorless in EDM type prism to well reflecting targets.
-

5.6 CPR105 Flat Prism

Description

The standard supplied Flat Prism (delivered with Builder 200 and 300) has two different reflective surfaces. The highly reflective cat-eye surface can be used for measurements up to 250 m. The reflective tape has printed crosshairs for precise aiming at close range. The closer the Flat prism is mounted to the ground, the more accurate it can be positioned over the measured point. For more precise positioning at higher prism positions, the GLS111 reflector pole with GAD105 adapter is recommended.

Prism mounting



5.7

CPR111 Builder Prism, True-Zero Offset


Description

This prism with true-zero offset is only delivered with the Builder 400 and 500. The closer the prism is mounted to the ground, the more accurate it can be positioned over the measured point. For more precise positioning at higher prism positions, the GLS111 reflector pole with GAD105 adapter is recommended.



To guarantee the accuracy the prism must be aligned well. If it is not or the line of sight is very steep it is recommended to aim the middle of the yellow arrows on the prism frame.

Prism mounting



6 Configuration Mode

6.1 Overview

Description

The **CONFIG** mode is used for:

- creating user specific settings in order to adapt the instrument to your own requirements.
- setting date and time.
- setting units.
- setting communication parameters.





Descriptions apply in general to Builder 200 or higher. Available options depend on the model.


6.2

Accessing

Access step-by-step



Step	Description
1.	Turn on the instrument by pressing the  key.
2.	Level up the instrument. Refer to "5.2 Instrument Setup" for more information.
3.	Press  until CONFIG mode is active.



Example of a configuration screen


CONFIG	THEO	>PROG	>DATA	>
Laser Pointer	:	Off		
Tracking	:	Off		
Hz Increment	:	Right		
V-Setting	:	Zenith		
Compensator	:	On		
DISP	COM	TIME		
DISP				To set configurations regarding display.
COM				To set communication type and parameter.
TIME				To set date and time.



Description of fields for main configuration screen


Field	Option	Description
<Laser Pointer:> (only Builder 200, 300 and 500)	Off On	Turns off the visible laser beam. Turns on the visible laser beam.
<Tracking:> (Builder 200 or higher)	Off On	Turns off continuous distance measure mode. Turns on continuous distance measure mode.
<Hz Increment:>	Right Left	Sets horizontal angle to clockwise direction measurement. Sets horizontal angle to counter-clockwise direction measurement.

Field	Option	Description
<p><V Setting:></p>	<p>Zenith</p>	<p>Sets the vertical angle. Zenith=0°; Horizon=90°</p> 
	<p>Horizon</p>	<p>Zenith=90°; Horizon=0° Vertical angles are positive above the horizon and negative below it.</p> 

Field	Option	Description
	V(%)	<p>Vertical angles are expressed in % with positive above the horizon and negative below it. 100% corresponds to an vertical angle of 45° (50 gon, 800 mil).</p> <p> The % value increases rapidly. ---% appears on the display above 300%.</p> 
<Compensator:>	On	<p>Turns on the compensator. Vertical angles are relative to the plumb line. The horizontal angle is corrected for the transversal tilt errors, if <Hz Correction: On>. Refer to "14 Check & Adjust" for more information.</p>


Field	Option	Description
	Off	<p data-bbox="710 182 1368 239">Turns off the compensator. Vertical angles are relative to vertical/standing axis.</p> <p data-bbox="710 280 1368 436">If the instrument is used on an unstable base, for example shaking platform, ship, etc. the compensator should be switched off. This avoids the compensator drifting out of its measuring range and interrupting the measuring process by indicating an error.</p> <p data-bbox="717 446 783 477"> The compensator setting remains active even after the instrument is switched off.</p>
<Beep:>	Off Key Key&Sect Sector	<p data-bbox="710 526 1151 552">Turns key beep and sector beep off.</p> <p data-bbox="710 572 1001 598">Turns only key beep on.</p> <p data-bbox="710 619 1365 676">Turns key beep and sector beep on. Turns layout beep in Layout application on.</p> <p data-bbox="710 697 1326 754">Turns sector beep on. Turns layout beep in Layout application on.</p>


Field	Option	Description
		<p>The key beep is an acoustic signal after each keystroke. The sector beep is an acoustic signal which sounds if horizontal angle is 0°, 90°, 180°, 270° or 0, 100, 200, 300 gon.</p> <p> The sector beep is useful for staking out right angles.</p> <p>Example for sector beep:</p> 

Field	Option	Description
		1 No beep 2 Fast beep, interrupted; from 95.0 to 99.5 gon and 105.0 to 100.5 gon 3 Permanent beep; from 99.5 to 99.995 gon and from 100.5 to 100.005 gon
<Auto Off:>	Enable	Sets the behaviour of power down and instrument. The instrument is turned off after 20 minutes without any action, for example no key pressed; Vertical and horizontal angle deviation is $\leq \pm 3'$.
	Disable	The instrument is turned on permanently.  Battery discharges quicker.
<Measure&Record:>	MEAS/REC	Assigns separated or combined measurement functionality to middle softkey button in all measure screens. Starts distance and angle measurements without saving measured values. After measurement displayed values can be saved with RECORD.
	ALL-in-1	Starts distance and angle measurements and saves measured values in one step.

Field	Option	Description
	MEASURE	Starts distance and angle measurements without saving measured values in certain applications. It is not possible to save any values.

Description of fields for display configuration screen

Field	Option	Description
<Contrast:>	From 10% to 100%	Adjusts the contrast level for the display immediately.
<Display Heater:>	On or Off	Turns the display heater immediately on and off.  The display heater is automatically activated when the display illumination is on and the instrument temperature is $\leq 5^{\circ}\text{C}$.
<Angle Unit:>	° ' "	The units shown for all angular and coordinate related fields. Degree sexagesimal: possible angle values: 0° to $359^{\circ}59'59''$

Field	Option	Description
	Dec.deg	Degree decimal: possible angle values: 0° to 359.999°
	Gon	Gon: possible angle values: 0 gon to 399.999 gon
	Mil	Mil: possible angle values: 0 to 6399.99mil  The setting of the angle units can be changed at any time. The actual displayed values are converted according to the selected unit.
<Minimum Reading:>		The number of decimal places shown for all angular fields. This is for data display and does not apply to data export or storage.
	Precise (except 9" models)	0° 00' 01" for <Angle Unit: ° ' ''>. 0.0001 for <Angle Unit: Gon> and <Angle Unit: Dec.deg>. 0.01 for <Angle Unit: Mil>.

Field	Option	Description
	Standard or Precise (only 9" models)	0° 00' 05" for <Angle Unit: ° ' ''>. 0.001 for <Angle Unit: Gon> and <Angle Unit: Dec.deg>. 0.05 for <Angle Unit: Mil>.
	Simple or Standard (only 9" models)	0° 00' 10" for <Angle Unit: ° ' ''>. 0.005 for <Angle Unit: Gon> and <Angle Unit: Dec.deg>. 0.1 for <Angle Unit: Mil>.
	Simple (only 9" models)	0° 00' 30" for <Angle Unit: ° ' ''>. 0.010 for <Angle Unit: Gon> and <Angle Unit: Dec.deg>. 0.5 for <Angle Unit: Mil>.
<Distance Unit:>	Meter ft-in1/16 Us-ft INT-ft	The units shown for all distance and coordinate related fields. Metres [m] US feet, inches and 1/16 inches (0' 00 0/16 fi) [ft] US feet [ft] International feet [fi]
<Language:>		The current loaded language(s) are shown.

Field	Option	Description
<Lang. Dialog:>		If two or more languages are loaded onto the instrument, a dialog to choose the language can be shown directly after switching on the instrument.
	On	The language dialog is shown as startup dialog.
	Off	The language dialog is not shown as startup dialog.

Description of fields for time configuration screen

Field	Option	Description
<Time Format:>	24 hours or 12 hours (am/pm)	Shown time format in all time related fields.
<Date Format:>	dd.mm.yyyy, mm.dd.yyyy, or yyyy.mm.dd	Shown date format in all date related fields.


6.3 Communication Parameters

Description

Data can be stored in internal memory or to an external device such as PDA, Data Collector or PC through the RS232 interface, the mini USB port or via Bluetooth. The available options depend on the Builder model.

For data transfer between instrument and an external device the communication parameters of the intended communication type must be set.

Example of a communication parameter screen



Field	Option	Description
Data Output	RS232	Data is recorded via the serial interface. For this purpose, a data storage device must be connected to the serial interface.
	Int. Mem.	All data is recorded in the internal memory.
	USB	Data is recorded via the mini USB interface. For this purpose, a data storage device must be connected to the mini USB port (for Builder 300 or higher).
	Bluetooth	Data is recorded via Bluetooth. For this purpose, a data storage device must be connected using a successfully established Bluetooth connection (for Builder 500 only).
Baudrate	2400, 4800, 9600, or 19200, 38400 (Builder 200 or higher), 57600 (Builder 300 or higher) and 115200 (only Builder 400 and 500)	Frequency of data transfer from receiver to device in bits per second.

Field	Option	Description
Databits	7	Number of bits in a block of digital data. Set automatically if <Parity:> Even or Odd .
	8	Set automatically if <Parity:> None .
Parity	None, Even or Odd	Error checksum at the end of a block of digital data.
Endmark	CR/LF	The terminator is a carriage return followed by a linefeed.
	CR	The terminator is a carriage return.
Stopbits	1	Number of bits at the end of a block of digital data.
Bluetooth PIN		Set user-defined Bluetooth PIN with 4 characters. 0000 is set by default.



Standard RS232

Standard RS232 is supported by default.

Field	Option
Baudrate	<ul style="list-style-type: none"> • 38400 for Builder 200 • 57600 for Builder 300 • 115200 for Builder 400 and 500




Field	Option
Databits	8
Parity	None
Endmark	CR/LF
Stopbits	1

Set communication parameters step-by-step



1. Make sure that **CONFIG** Mode is active.
 2. Press **COM** to access communication parameter setting.
 3. Press  to set focus on desired field.
 4. Press  to toggle through the settings and select desired field.
 5. Accept with **OK**.
- The setting is accepted.

6.4 How to Make a Setting

How to make a setting with a choicelist step-by-step

1. Make sure that **CONFIG** Mode is active.
 2. Press  to set focus on desired field.
 3. Press  to access the choicelist.
 4. Press  to toggle through the list and set focus on desired field.
 5. Accept with **OK**.
-


How to make a setting with a choicefield step-by-step

1. Make sure that **CONFIG** Mode is active.
 2. Press  to set focus on desired field.
 3. Press  to toggle through the settings and select desired field.
 4. Accept with **OK**.
-

6.5

Pin Assignment

Port at the instrument

Diagram	Pin	Name	Description	Direction
	a	PWR_IN	Power input: + 12 V nominal (11 - 16 V)	In
	b	-	Not used	-
	c	GND	Single ground	-
	d	Rx	RS232, receive	In
	e	Tx	RS232, transmit	Out

7 Theodolite Mode

7.1 Overview

Description



The **THEO** mode is used for:

- levelling up the instrument with the electronic level and adjusting the intensity of the laser plummet
 - reading off the current horizontal and vertical angle
 - setting horizontal angle to zero
 - setting any horizontal angle
 - quick setting of horizontal and vertical angle direction
-


7.2

Accessing



Access step-by-step


1. Turn on the instrument by pressing the  key.
2. Level up the instrument. Refer to "5.2 Instrument Setup" for more information.
3. Press  until **THEO** mode is active.

Example of a theodolite screen



- Hz HOLD** To set any horizontal angle.
- Hz = 0** To set horizontal angle to 0.000.
- LEVEL** To switch on electronic level and laser plummet.

Field	Description
Hz 	The current horizontal angle in "clockwise direction measurement".
Hz 	The current horizontal angle in "anticlockwise direction measurement".

Field	Description
	 Thanks to dual axis compensation, the Builder is able to adjust the horizontal angle reading accordingly. Therefore, turning the telescope vertically might cause the horizontal angle to change. The change in <Hz:> is the compensation of the standing axis tilt. The more precise the instrument is leveled, the less the horizontal angle needs to be compensated.
v ↑	The current vertical angle with Zenith=0° and Horizon=90°.
v →	The current vertical angle with Zenith=90° and Horizon=0°.
v %	The current vertical angle in percentage.

7.3

Set horizontal angle to 0.000 step-by-step

How to Set Horizontal Angle to 0.000

1. Make sure that **THEO** Mode is active.
2. Turn telescope and aim at desired target point.
3. Press **Hz = 0**.
4. Accept with **OK**.

The horizontal angle is set to 0.000.

7.4

How to Set Any Horizontal Angle

Set any horizontal angle step-by-step



1. Make sure that **THEO** Mode is active.
2. Turn telescope to desired horizontal angle.
3. Press **Hz hold**.
4. Turn telescope and aim at a target point.
5. Accept with **OK**.

The indicated horizontal angle is set.


7.5

Quick Setting of Horizontal Angle and Vertical Angle Direction Measurement

Quick setting of horizontal angle direction measurement step-by-step

1. Make sure that **THEO** Mode is active.
 2. Press  to set horizontal angle to "clockwise direction measurement" or press  to set horizontal angle to "counter-clockwise direction measurement".
The horizontal angle is set to clockwise direction or counter-clockwise direction measurement.
-

Quick setting of vertical angle direction measurement step-by-step

1. Make sure that **THEO** Mode is active.
 2. Press  to set vertical angle to the zenith, the horizon or in percentage.
The vertical angle is set.
-

8 Program Mode, for Builder 200 or higher

8.1 Overview

Description

The **PROG** mode is used for:

- distance measurements
 - Station Setup
 - working with application programs
-





Descriptions apply to Builder 200 or higher. Available options depend on the model.


8.2

Accessing

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Level up the instrument. Refer to "5.2 Instrument Setup" for more information.
3. Press  until **PROG** mode is active.

Example of an application program screen



APPL

To start application programs menu.

M&R

To measure and display distances and record data.
To turn on/off laser pointer by pressing for approximately 5 seconds in all measure screens (except Builder 400).
To turn on/off Tracking mode by pressing for approximately 5 seconds in Layout application.

SETUP

To start station setup menu.

8.3

Pointsearch



Description

Pointsearch is a global function used by applications and setups, for example to find internally saved measured or fixed points.



Descriptions apply to Builder 300 or higher. Available options depend on the model.

Pointsearch step-by-step

1. Turn on the instrument by pressing the  key.
2. Make sure that **PROG** mode is active.
3. Choose an application, for example Layout.
4. Press **APPL** to go back to application menu. (Only in application Layout)
5. Press **P-List**.
6. Enter in **<Search ID:>** the point identifier for that should be searched.
7. Press **OK**.
8. Press  to select the point.
9. Press **SELECT**.

Now the point appears in the application that was active before.

Example of a Pointsearch screen

CONFIG	THEO	PROG	DATA
Point List Search			
Search ID:	231		
230			
231			
232			
DELETE		OK	
		ABC1	

DELETE To remove the last character.
OK To access the point list.
ABC1 To switch between numeric and alphanumeric input.

Field	Description
<Search ID:>	Enter the point to be searched for.
231	The middle data point matches the entered information best.

Wildcard search

Instead of a certain Point ID a wildcard represented by a * can be used as Search ID. The following options are available:

- *5 selects a list of Point IDs ending with a 5, for example 15, 25, 1375 ...
- 5* selects a list of Point IDs beginning with a 5, for example 51, 58, 512 ...
- *5* selects a list of Point IDs containing a 5, for example 153, 3856, 15627 ...

8.4

Measure and Record

Possibilities

The Measure and Record function can be used in three different ways:


- Measure and record in one step (**ALL-in-1**)
 - Combining the functions **MEASURE** and **RECORD**
 - Using **MEASURE** only
-

Measure and record (ALL-in-1) step-by-step

1. Make sure that **PROG** Mode is active.
 2. Make sure that **<Measure&Record: ALL-in-1>** is set.
Refer to "6 Configuration Mode" for information on how to make the setting.
 3. Position the prism at the point to be measured.
 4. Press **M&R** to measure and record the distance and angles to the point.
-

Combining MEASURE and RECORD step-by- step

The key combination of **MEASURE** and **RECORD** can be used to measure non accessible points with the prism, for example building corners.



1. Make sure that **PROG** Mode is active.
 2. Make sure that **<Measure&Record: MEAS/REC>** is set.
Refer to "6 Configuration Mode" for information on how to make the setting.
 3. Position the prism at the same distance from the instrument as the building corner to be measured.
 4. Press **MEASURE** to measure the distance.
 5. Aim at the building corner.
 6. Press **RECORD** to store the measured distance to the prism and the angles to the corner of the house.
-

**MEASURE only
step-by-step**

1. Make sure that **PROG** Mode is active.
2. Make sure that **<Measure&Record: MEASURE>** is set.
Refer to "6 Configuration Mode" for information on how to make the setting.
3. Position the prism at the point to be measured.
4. Press **MEASURE** to measure the distance.
5. No points or results are stored and the next measurement can be started directly by pressing **MEASURE** again.



Use Switch Key 2 to switch between **MEASURE** only and **All-in-1** respectively **MEAS/REC** depending on the previously chosen Measure mode (only for Builder 400 and 500).

9 Station Setup, for Builder 200 or higher

9.1 Overview

Description

The Setup programs can be used to set up and orientate the instrument.

Three Setup options with different Setup methods are available:

- Control line
- Coordinates
- Height

Description of Setup menu options

Setup Option	Setup Method	Description
Control line	Over 1st point	To set up the instrument on the startpoint of a control line.
	Anywhere	To set up the instrument along a control line.
Coordinates	Over Known Point	To set up the instrument over a known point and orientate to a known azimuth or to up to five backsight points.
	Anywhere	To set up the instrument on an unknown point and orientate by measuring angles and distances to up to five known target points.

Setup Option	Setup Method	Description
Height	Height Transfer	To determine the height of the position of the instrument from measurements to up to five target points with known height.

For the different Setup methods, different types of data and a different number of control points have to be available.



Descriptions apply in general to Builder 200 or higher. Available options depend on the model.

9.2 Setup Option 1: Establish Control Line

9.2.1 General

Description

The Setup Option **Control Line** is used to set up the instrument in relation to a control line. All further measuring points and points to be staked are in relation to the control line.


9.2.2

Establish Control Line - Over 1st Point

Description

The Setup method **Control Line - Over 1st Point** is used to set the station coordinates to $E_0=0.000$, $N_0=0.000$, $H_0=0.000$ and the orientation to 0.000.

Diagram



P0	Station
P1	Target point

9.2.3

Establish Control Line - Anywhere


Description

The Setup method **Establish Control Line - Anywhere** is used to set up the instrument along a control line. The coordinates of line start point are set to $E_0=0.000$, $N_0=0.000$ and $H_0=0.000$. The orientation is set to 0.000 in the direction of the second line point. Furthermore line startpoint can be shifted by entering or measuring line and offset values.



The height of line startpoint P1 is used as the reference height for all further measurements.

Diagram




P0	Station
P1	Line start point
P2	Second line point

Shifting Line Start-point

In Setup method **Establish Control line - Anywhere** line startpoint can be shifted to use another origin for the local coordinate system. If the entered line value is positive the start point moves forward otherwise backward. The start point gets a rightward shift if the entered offset value is positive otherwise a leftward shift.

Diagram



P1	Line start point
P2	Second line point
P3	Shifted line start point, new origin of local coordinate system
a	Offset value for shift
b	Line value for shift

Example of a dialog
for shifting line
startpoint

CONFIG THEO **PROG** DATA

Enter or measure shift

Line : **6.500 m**

Offset : **-1.000 m**

Set=0 **OK** **MEAS**

- Set=0** To set line or offset values to zero.
- OK** To accept entered/measured line or offset values.
- MEAS** To measure new origin of local coordinate system.

9.3

Setup Option 2: Establish Coordinates

9.3.1

General

Description


The Setup Option **Coordinates** is used to set up the instrument in relation to a local or global coordinate system. All further measuring points and points to be staked are in relation to the coordinate system.

9.3.2 Establish Coordinates - Over Known Point

Description

The Setup method **Establish Coordinates - Over Known Point** is used to set up the instrument on a known point and orient to a known azimuth or to up to five known backsight points. If more than one backsight point was used, the quality of the orientation is shown in the result screen.

Diagram



Example of a result screen

CONFIG	THEO	PROG	DATA
Orient. Std. Dev. : +0.0003 g			
Control point accuracy			
4	:	-0.0003 g	
3	:	+0.0002 g	
2	:	+0.0002 g	
REDO		OK	

REDO To delete or re-measure a used backsight point.


OK To accept computed/measured values.

9.3.3 Establish Coordinates - Anywhere

Description

The Setup method **Establish Coordinates - Anywhere** is used to set up the instrument on an unknown point and set the orientation by measuring angles and distances to a minimum of two known target points and a maximum of five target points. Beside the computation of the position, the height is also computed if the measured target point has a known height. If more than two known target points were used, the quality of the new station is shown in the result screen.

Diagram



Example of a result screen

CONFIG	THEO	PROG	DATA
Pos. Std. Dev.	:	0.008	m
Pos control point accuracy			
P+0004	:	0.004	m
P+0003	:	0.018	m
P+0002	:	0.012	m
REDO OK HGT			

- REDO** To delete or re-measure a used target point.
- OK** To accept computed/measured values.
- HGT** To switch to height result screen.


9.4 Setup Option 3: Establish Height

9.4.1 General

Description

The Setup Option **Establish Height** is used to enter the station height, instrument height and reflector height. All further measuring points and points to be staked are in relation to the entered values.

Enter station height, instrument height and reflector height step-by-step

1. Make sure that **PROG** Mode is active.
2. Press **SETUP**.
3. Press  to highlight Setup option **Height**.
4. If a value for station height is shown, the value is related to the chosen setup method of **Control Line** or **Coordinates**. This value may be changed or in case of **<----->**, a height can be entered.
5. Enter station height, instrument height and reflector height.
6. Accept with **OK**.


9.4.2

Height Transfer

Description

The Setup method **Height Transfer** is used to determine the height of the position of the instrument from measurements to up to five target points with known height.

Diagram



- P0 Station
- P1 First point with known height
- P2 Second point with known height
- P3 Third point with known height

Example of a result screen

CONFIG	THEO	PROG	DATA
Height	Std. Dev.	:	0.008 m
Hgt control point accuracy			
P+0004	:	0.004 m	
P+0003	:	0.018 m	
P+0002	:	0.012 m	
REDO		OK	

- REDO To delete or re-measure a used point.
- OK To accept computed/measured values.

10 Application Programs, for Builder 200 or higher

10.1 Overview

Description

Application programs are predefined programs, that cover a wide spectrum of construction tasks and facilitate daily work in the field. Up to nine different application programs are available.

Description of application programs

Application program	Description
Layout	To stake out points.
As Built	To measure points with line, offset and height difference or with easting, northing and height.
Angle & Distance	To measure points with horizontal angle, horizontal distance and height difference.
Tie Distance	To determine horizontal distance, height difference and grade between two measured points.
Area & Volume	To determine area and perimeter of a plane or tilted surface together with the capability to calculate its volume with a constant height. Furthermore to determine the volume of an irregular surface such as a stockpile or excavation pit.

Application program	Description
Hidden Point	To measure points that are not directly visible. Two methods: using a rod with two targets, alternatively enter line of sight shift and/or side shift manually.
COGO	Performs coordinate geometry calculations such as intersections and more.
Layout Line/Arc/Spiral	Layout and as-built check of lines, arcs or spirals. Includes road element and grid layout.
Measure & Descriptor	To measure and encode points.



Descriptions on this page apply to Builder 300 or higher. Available options depend on the model.


10.2

Layout

Description

The application program **Layout** is used to place markers in the field at predetermined points. These predetermined points are the points to be staked. The points to be staked are defined by entering line and offset or easting, northing and height depending on the used setup method. For Builder 300 or higher the points can also be selected from the memory even via a wildcard search. The program calculates and displays the difference between the measured point and the point to be staked.

Diagram



- | | |
|----|---------------------------------|
| P0 | Station |
| P1 | Current position |
| P2 | Point to be staked |
| d1 | <↑:> go forward or <↓:> go back |
| d2 | <→:> go right or <←:> left |
| d3 | <↑:> fill or <↓:> cut |

Example of a layout application screen

CONFIG	THEO	PROG	DATA
Layout		x ⊗	
Pt:	x		
	P+0011 (↔)		
Line:	-4.700 m	↓	0.254 m
Offs:	25.000 m	←	0.345 m
H :	0.500 m	↑	0.362 m
APPL		MEASURE	
SETUP			

APPL

To start application programs menu.

MEASURE

To measure and display stake out differences.

To turn on/off Tracking mode by pressing for approximately 5 seconds.

SETUP

To start station setup menu.

Field	Description
<Pt:>	The identifier for the points to be staked. Available for Builder 300 or higher.
<Line:>	Available if a Setup method with Control Line was used. Longitudinal offset of the start point of the control line in the direction of the second point of the control line. Line is positive in the direction from line start point to second line point.
<Offs:>	Available if a Setup method with Control Line was used. Cross offset to the control line. Offset is positive at the right hand side of the control line.

Field	Description
<E:>	Available if a Setup method with Coordinates was used. Easting of point to be staked.
<N:>	Available if a Setup method with Coordinates was used. Northing of point to be staked.
<H:>	Height of point to be staked.

Elements of the graphical display

In application program **Layout** a graphical display provides a guide to find the point to be staked out.

Element	Description
⊗	Reflector
X	Point to be staked
<↑:> / <↓:>	go forward / back
<←:> / <→:>	go left / right
<↑:> / <↓:>	fill / cut

10.3


As Built

Description

The application program **As built** is used for measuring an unlimited number of points. The program shows line and offset values or easting, northing and height depending on the used Setup method.

Example of an As Built application screen

Displayed graphic and available values depend on the used Setup method.




- APPL** To start application programs menu.
- M&R** To measure and display distances and record data.
To turn on/off laser pointer by pressing for approximately 5 seconds (except Builder 400).
- SETUP** To start station setup menu.

Field	Description
<Pt:>	The identifier for the measured points. Available for Builder 300 or higher.

Field	Description
<Line:>	Available if a Setup method with Control Line was used. Longitudinal offset of the start point of the control line in the direction of the second point of the control line. Line is positive in the direction from line start point to second line point.
<Offs:>	Available if a Setup method with Control Line was used. Cross offset to the control line. Offset is positive at the right hand side of the control line.
<E:>	Available if a Setup method with Coordinates was used. Easting of measured point.
<N:>	Available if a Setup method with Coordinates was used. Northing of measured point.
<H:>	Height of measured point.

Diagram



- P0 Station
- P1 Line start point
- P2 Second line point
- P3 Measured point
- d1 Line
- d2 Offset

Elements of the graphical display

In application program **As Built** a graphical display shows the position of the station, used control points, the reflector and the last 50 measured points.

Element	Description
	Station
	Control point
	Reflector

Element	Description
+	Measured point
	North
	Control Line

10.4 Angle & Distance


Description

The application program **Angle & Distance** is used for measuring an unlimited number of points. The program shows horizontal angle, horizontal distance and height.

Example of an Angle & Distance application screen



Displayed graphic and available values depend on the used Setup method.




APPL To start application programs menu.

M&R To measure and display distances and record data.
To turn on/off laser pointer by pressing for approximately 5 seconds (except Builder 400).

SETUP To start station setup menu.

Field	Description
<Pt:>	The identifier for the measured points. Available for Builder 300 or higher.

Field	Description
<Hz:>	The current horizontal angle.
	The measured horizontal distance to the target point.
<H:>	Height of measured point.

Elements of the graphical display

Refer to "10.3 As Built" for more information.

10.5 Tie Distance

Description

The application program **Tie Distance** is used to compute horizontal distance, height difference and grade between two target points. The target points have to be measured.

The user can choose between two different methods:



- Polygonal (P1-P2, P2-P3); 
- Radial (P1-P2, P1-P3); 

Diagram Polygonal (P1-P2, P2-P3)





Diagram Radial (P1-P2, P1-P3)






- P0 Station
- P1 Target point
- P2 Target point
- P3 Target point
- P4 Target point
- d1 Distance between P1 and P2
- d2 Distance between P1 and P3
- d3 Distance between P1 and P4

Example of a Tie Distance result screen

CONFIG	THEO	PROG	DATA
Tie Distance - Result !			
From :	Pt0001		█ █ █ █ █
To :	Pt0002		
Δ :	19.855 m		
Δ :	-0.243 m		
Grade :	-1.2 %		
OK			

OK To measure more points.

Field	Description
<From:>	The identifier for the first measured point. Available for Builder 300 or higher.
<To:>	The identifier for the second measured point. Available for Builder 300 or higher.
Δ 	Calculated horizontal distance between the measured points.
Δ 	Calculated height difference between the measured points.
<Grade:>	Calculated grade [%] between the measured points.
Δ 	Calculated slope distance between the measured points.

10.6

Area and Stockpile Volumes

Description

The application program **Area** with methods 'plane' and 'tilt' is used to compute area size of areas with max. 50 boundary points connected by straights. Furthermore a volume with constant height can be calculated.


The calculated area is projected onto the horizontal plane or projected onto the tilted reference plane depending on the chosen method. The tilted reference plane is computed and updated automatically after each measurement. It is determined out of all current boundary points by those three points that stretch the largest area.

Stockpile Volumes is an application for volume calculations without a plane or tilted area. For the calculations two boundaries have to be measured. The first one is the outer boundary, the second one is the inner boundary. Both boundaries must not cross each other for a proper calculation.

10.6.1 Area Application


Description

The boundary points have to be measured ordered, either in clockwise or anticlockwise direction.



The area is calculated and displayed once three points have been measured.

Example of an Area
Result screen


CONFIG	THEO	PROG	DATA
Area - Result !			
NoPt:	3		
Area:	240.017 m ²		
Peri:	74.804 m		
			
OK		VOLUME	

OK
VOLUME

To measure more points.
To calculate a volume with
constant height.

Field	Description
<NoPt:>	Number of measured points.
<Area:>	Calculated area.
<Peri:>	Calculated perimeter.

Diagram: Area application




- P0 Station
- P1 Start Point
- P2 Target Point
- P3 Target Point
- P4 Target Point
- a Constant height
- b Perimeter (tilt) of the tilted area stretched by all current measured points
- c Area (tilt), always closed to the start point P1 projected, onto the tilted reference plane
- d Volume (tilt) = $c \times a$
- e Perimeter (plane) of the plane area stretched by all current measured points
- f Area (plane), always closed to the start point P1, projected onto the horizontal plane
- g Volume (plane) = $f \times a$

10.6.2

Stockpile Volumes Application

Description

The points of the first (outer) boundary have to be measured ordered, either in clockwise or anticlockwise direction. The same is for the second (inner) boundary.



OK
BREAKL.

To measure more points.
To start measuring the second (inner) boundary.

Field	Description
<NoPt:>	Number of measured points.
<Area:>	Calculated area.
<Peri:>	Calculated perimeter.



10.7

Hidden Point (optional)

Description

The application program **Hidden Point** allows measurements to a point that is not directly visible. The point can be determined by a rod or by entering the shift in the line of sight and the side shift.


The user can choose between two different methods:

- Rod 
- Shift 




The application program Hidden Point is only available for the Builder 300 or higher. The program can be started in total 40 times for trial. Afterwards you have to enter the license code.

Diagram Rod



- a) Hidden Point
- b) Rod length
- c) First reflector
- d) Second reflector

Diagram Shift (Example)



- P0 Station
- P1 Reflector
- P2 Hidden point
- d1 Line of sight
- d2 Side shift

Example of Hidden Point result screen

CONFIG	THEO	PROG	DATA
Shift Result			
New Pt:			
P10013			
E :	99.859	m	
N :	5.920	m	
H :	-0.200	m	
OK			







OK

To measure next hidden point.

Field	Description
<RL=Rod Length:>	Length of used rod.
<Line of sight:>	Longitudinal offset from reflector in direction to the instrument.
<Side shift:>	Cross offset of hidden point to the line instrument-reflector.
<E:>	Easting of hidden point.
<N:>	Northing of hidden point.
<H:>	Height of hidden point.

Elements of the graphical display

In application program Hidden Point a graphical display shows the position of the station, the reflector and the hidden point.

Element	Description
	Station
	Line instrument-reflector
	Reflector/first measured target of the rod
	Hidden point
	North
	Control Line

10.8

COGO (optional)

Description

The application program **COGO** is an application program to perform **coordinate geometry** calculations such as:

- Coordinates of points
- Directions between points
- Distances between points

The COGO calculation methods are:


- Intersections
- Line Extension
- Offset Line&Plane
- Traverse and Inverse



The application program COGO is only available for the Builder 300 or higher. The program can be started in total 40 times for trial. Afterwards you have to enter the license code.

Diagram Intersections

Two Distances




Known

- P1 First known point
- P2 Second known point
- r1 Radius, as defined by the distance from P1 to P3 or P4
- r2 Radius, as defined by the distance from P2 to P3 or P4

Unknown

- P3 First COGO point
- P4 Second COGO point

Direction & Distance




Known

- P1 First known point
- P2 Second known point
- α Direction from P1 to P3 and P4
- r Radius, as defined by distance from P2 to P3 and P4

Unknown

- P3 First COGO point
- P4 Second COGO point

Two Lines




Known

- P1 First known point of line 1
- P2 Second known point of line 1
- P3 First known point of line 2
- P4 Second known point of line 2
- a Line 1
- b Line 2

Unknown

- P5 COGO point

Two Directions



Known


- P1 First known point
- P2 Second known point
- α_1 Direction from P1 to P3
- α_2 Direction from P2 to P3

Unknown

- P3 COGO point

Diagram Line Extension

The **Extension** routine computes extended point from base line.



Known

P1 Baseline start point

P2 Baseline end point


ΔL Distance from end point

Unknown

P3 Extended point

**Diagram Offset
Line & Plane**

Line Offset




Known

- P1 Baseline start point
- P2 Baseline end point
- P3 Offset point

Unknown

- P4 Base point
- d1 Line
- d2 Offset

Plane Offset




Known

- P1 Point 1 which defines plane
- P2 Point 2 which defines plane
- P3 Point 3 which defines plane
- P4 Offset point

Unknown

- P5 COGO point
- d1 Offset

Set Point by Offset



Known


- P1 Baseline start point
- P2 Baseline end point
- d1 Line
- d2 Offset

Unknown

- P3 Offset point

Diagram Inverse & Traverse

Inverse




Known

- P1 First known point
- P2 Second known point

Unknown

- d1 Horizontal distance between P1 and P2
- d2 Height difference between P1 and P2
- α Direction from P1 to P2

Traverse

**Known**

- P1 Known point
- α Direction from P1 to P2
- d1 Horizontal distance between P1 and P2
- d2 Positive offset to the right
- d3 Negative offset to the left

Unknown



- P2 COGO point without offset
- P3 COGO point with positive offset
- P4 COGO point with negative offset

Example of a COGO
Result screen

CONFIG	THEO	PROG	DATA
COGO: RESULT			
New Pt:			
		P+0013	
E:	2.834 m		
N:	19.938 m		
LAYOUT		OK	







- LAYOUT** To stake out new COGO point.
- OK** To calculate next point.

Refer also to the applications before.

Field	Description
<Direction:>	Direction between two points.
<Dist.:>	Distance between two points.
<Line:>	Longitudinal offset from the start point of the baseline.
<Offset:>	Cross offset to the baseline.
Δ 	Calculated horizontal distance between two points.
Δ 	Calculated height difference between two points.
<New Point:>	The identifier for the new COGO points.
<E:>	Easting of new COGO point.
<N:>	Northing of new COGO point.
<H:>	Height of new COGO point.

Elements of the graphical display

In application program COGO a graphical display shows the position of the station, used known points, directions, distances and the new calculated point.

Element	Description
	Station
	Direction between two points
	Distance between two points
	Distance and direction between two points
	Known point
	New calculated COGO point

Refer to "10.2 Layout" for more information.

10.9

Layout Line/Arc/Spiral (optional)


Description

The application program **Layout Line/Arc/Spiral** facilitates the easy stake out or checking of lines, grids, arcs, segments and spirals. Besides the usual layout of these elements, this application allows the user to stake out and check points relative to a road alignment.




The application program Layout Line/Arc/Spiral is only available for the Builder 300 or higher. The program can be started in total 40 times for trial. Afterwards you have to enter the license code.

Diagram Line




SP	Start point
EP	End point
RP1	Reference line start point
RP2	Reference line end point
SF	Shift forward
SR	Shift right
R	Rotate
d1	Line
d2	Offset
P	Point to stake or check

Diagram Arc




- SP Start point of arc
- EP End point of arc
- CP Center point of circle
- R Radius of arc
- D Direction
- d1 Line
- d2 Offset
- P Point to stake or check
- CW Arc-turn clockwise
- ACW Arc-turn anticlockwise

Diagram Spiral



- SP Start point of spiral
- EP End point of spiral
- R Radius
- L Length
- A Spiral parameter
- CW Spiral-turn clockwise
- ACW Spiral-turn anticlockwise
- P Point to stake or check
- d1 Line
- d2 Offset
- B,C Spiral direction (in, out)

Diagram Road



- A Line
- B Spiral
- C Arc

- R Radius

- a Offset left
- b Offset right
- c Interval
- d Defined chainage



It's only possible to work with one element (Line or Arc or Spiral).

Example of Layout
Line/Arc/Spiral
result screen

CONFIG	THEO	PROG	DATA
Check Arc Pt:			
Pt: P+0013			
Chai:	2.834	m	
Offs:	19.938	m	
Δ ▲:	0.243	m	
APPL		M & R	

APPL

To start application programs menu.




M & R


To measure and display distances and record data.
To turn on /off laser pointer by pressing for approximately 5 seconds (except Builder 400).

Field	Description
<Chai:>	Chainage.
<Line:>	Longitudinal offset of measured point from start point of reference line.
<Arc:>	Longitudinal offset of measured point from start point of arc.
<Spir:>	Longitudinal offset of measured point from start point of spiral.
<Offs:>	Cross offset of measured point to reference element.
Δ ▲	Calculated height difference between start point of the element and measured point.

Elements of the graphical display

In application program Layout Line/Arc/Spiral a graphical display shows the position of the station, reference element with its definitions, the reflector and the last 50 measured points.

Element	Description
	Station
	Control point
	Reflector

Element	Description
+	Measured point
	Turn of element

Refer to "10.2 Layout" for more information.

10.10

Measure & Descriptor

Description

In the program **Measure & Descriptor** it is possible to give each measured point a descriptor. Further it shows slope and horizontal distances and height differences.



The application program Measure & Descriptor is only available for the Builder 400 and 500.

Example of Measure & Descriptor application screen

CONFIG	THEO	PROG	DATA
Measure & Descriptor			
Pt:			P+0010
Desc.:			TREE
↙:			5.056 m
↘:			5.055 m
↕:			-0.100 m
APPL		M & R	SETUP

APPL

To start application programs menu.




M & R

To measure and display distances and record data. To turn on /off laser pointer by pressing for approximately 5 seconds (except Builder 400).

SETUP

To start station setup menu.

Field	Description
<Pt:>	The identifier for the measured points.
<Desc.:>	Entry of the description.

Field	Description
	The measured slope distance to the target point.
	The horizontal distance to the target point.
	The height difference to the target point.

11 Data Management Mode, for Builder 300 or higher

11.1 Overview

Description

The **DATA** mode is used for:

- creating, viewing and deleting data in the field
 - data exchange with the USB memory stick
-





Descriptions apply to Builder 300 or higher.

11.2

Accessing

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Level up the instrument. Refer to "5.2 Instrument Setup" for more information.
3. Press  until **DATA** mode is active.

Example of a data management screen

CONFIG)THEO)PROG	DATA		
Job :			PIPES		
Type:			Fixpoint	IMP/EXP	To import data from or export field data to USB memory stick.
Pt :			4		
E :			7.550 m		
N :			4.649 m	POINTS	To access the point management.
H :			0.803 m		
			IMP/EXP	POINTS	JOB
					To access the job management.

Field	Description
<Job:>	The current active job name.
<Type:>	Fixpoint, Measurement and Result.
<Pt:>	The active identifier for points.

Field	Description
<E:>	Easting coordinate.
<N:>	Northing coordinate.
<H:>	Height.

11.3

Jobs

Description

Jobs are a summary of different types of data, for example fixpoints, measurements, result, etc. The job definition consists of the input of job name, operator and remark. Additionally, the system generates time and date at the time of creation.

Active job

The active job is the one in which data is stored to. One job is always considered the active job.

Default job


A job called **Default** is always available on the instrument. The job **Default** is active until a user defined job is created and selected.

Create a new job step-by-step

1. Make sure that **DATA** Mode is active.
2. Press **JOB** to access job management.
3. Press **NEW** to create a new job.
4. Enter new job name.
5. Accept with **OK**.


The new job is set as active job.

View and select a job step-by-step

1. Make sure that **DATA** Mode is active.
2. Press **JOB** to access job management.
3. Press  to toggle through the jobs and select job.
4. Accept with **OK**.

The selected job is set as active job.

Delete a job step-by-step

1. Make sure that **DATA** Mode is active.
2. Press **JOB** to access job management.
3. Press  to toggle through the jobs and select job.
4. Press **DELETE**.
5. Accept with **YES**.

The selected job is deleted. Data is not recoverable.

11.4

Fixpoints


Description

Fixpoints contain at least a point identifier, easting and northing or height.

Fixpoints can be




- created, viewed and deleted in the field.
 - downloaded for data transfer to a further program.
 - uploaded, for example for stakeout operations.
-

Create a new fixpoint step-by- step




1. Make sure that **DATA** Mode is active.
2. Press  to set **<Type:> Fixpoint**.
3. Press **POINTS** to access point management.
4. Press **NEW PT** to create a new fixpoint.
5. Enter point identifier, easting, northing and/or height.
6. Accept with **OK**.

The new point is created.

**View a fixpoint
step-by-step**

1. Make sure that **DATA** Mode is active.
 2. Press  to set **<Type:> Fixpoint**.
 3. Press  to set focus on **<Pt:>**.
 4. Press  to toggle through the points.
The coordinates are displayed on same screen.
-

**Delete a fixpoint
step-by-step**

1. Make sure that **DATA** Mode is active.
 2. Press  to set **<Type:> Fixpoint**.
 3. Press  to set focus on **<Pt:>**.
 4. Press  to toggle through the points and select point.
 5. Press **POINTS** to access point management.
 6. Press **DELETE** to delete point.
 7. Accept with **YES**.
- The selected point is deleted. Data is not recoverable.
-

11.5

Measurements




Description

Measurement data contains at least horizontal angle, vertical angle, horizontal distance, slope distance, height difference, data, time and if applicable, line, offset, easting, northing and height coordinates.

Measurement data can be:




- viewed
 - deleted
 - downloaded for data transfer to a further program
-

View a measurement step-by-step

1. Make sure that **DATA** Mode is active.
2. Press  to set **<Type:> Measurement**.
3. Press  to set focus on **<Pt:>**.
4. Press  to toggle through the points.
The coordinates are displayed on same screen.
5. Press **POINTS** to access point management.

Measurement values are displayed.

Delete a measurement step-by-step

1. Make sure that **DATA** Mode is active.
2. Press  to set **<Type:> Measurement**.
3. Press  to set focus on **<Pt:>**.
4. Press  to toggle through the points and select point.
5. Press **POINTS** to access point management.
6. Press **DELETE** to delete point.
7. Accept with **YES**.

The selected point is deleted. **Data is not recoverable.**



Deleting measurements is not available for application programs Tie Distance and Area because of the result calculation.

11.6

Result




Description

Result data contains a result identifier and the different values depending on the application. The applications from which these result data can be displayed are **Area** and **Tie Distance**.

Result data can be:

- viewed
 - downloaded for data transfer to a further program
-

View a result step-by-step

1. Make sure that **DATA** Mode is active.
2. Press  to set **<Type:> Result**.
3. Press  to set focus on **<Res.>**.
4. Press  to toggle through the results.
The first three rows of the result are displayed on the same screen.
5. Press **VIEW** to access result management.

Result values are displayed.

11.7 Data Transfer

Description

For data transfer use:

- Construction Data Manager
Simple office software which supports the exchange of Leica TPS data with the PC via cable, USB memory stick or Bluetooth, using a Windows® application.
-


11.7.1 USB Memory Stick - Import / Export

Description

Data can be exchanged between the internal memory of the instrument and a connected USB memory stick. The two different options for such a data exchange are Import and Export. Import means to load a GSI file from the USB memory stick into a job in the internal memory, Export means to extract data from a job into a GSI file which is placed on the USB memory stick.

The dialogue for Import and Export can be accessed via the Softkey button **IMP/EXP** in the **Data** page.

Example of an export screen




OK To accept settings.

Field	Option	Description
<Exchange mode:>	Export	Export screen is set as default.
	Import	To switch to Import screen.
<Data Type:>	Measurements	Only measurements will be exported.
	Meas.&Fixpoints	Measurements and Fixpoints will be exported.
	Fixpoints	Only Fixpoints will be exported.
<Job:>		Select the intended Job, the last used Job is selected as default.



The name of the resulting GSI file is automatically created accordingly to the name of the selected job! The file is stored in the **Data** folder on the USB memory stick!

Example of an Import screen



OK To accept settings.
NEW JOB To create a new job.

Field	Option	Description
<Exchange mode:>	Export Import	To switch to Export screen. Import screen.
<GSI-File:>		Select file from list of all available GSI files in the Data folder on the USB memory stick.
<To Job:>		Select the intended Job to import to, the last used Job is selected as default.



The GSI file for Import has to be stored into the **Data** folder on the USB memory stick!
It is automatically detected and provided in the selection list!

12 EDM Settings

12.1 EDM



Description

With the instrument different settings are available for measurements with red dot (without reflectors) and prism (with reflectors). The LED on the keyboard indicates the selected type. Depending on the selected type the selection of prism types is different. Red dot contains the Flat prism as the only one and is not displayed. Beside the settings of the EDM it is possible to set the reflector height.



Descriptions apply only to Builder 400 and 500.

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Press the  key.



EDM settings are not accessible during the following:

- **THEO Mode:** Level or orientation procedure is running.
- **PROG Mode:** „YES or NO“ decision, for example „Station and Orientation will be changed and set“ or Point List Search is running.
- **DATA Mode:** One of the procedures IMP/EXP, POINTS or JOB is running.

3. Make desired settings.
4. Accept with **OK**.

Example of EDM settings screen

EDM Settings
EDM Type : red dot
Laser Pointer : Off
Tracking : Off

hr : 1.500 m
OK

OK
RANGE

To accept settings.
To disable limited distance measurement. Button disappears when entered once.

Field	Option	Description
<EDM Type:>	prism	Fine measuring type for high precision measurements with prisms.
	red dot	For distance measurements without prisms.
<Laser Pointer> (only Builder 500)	Off	Turns off the visible laser beam.
	On	Turns on the visible laser beam.
<Tracking:>	Off	Turns off continuous distance measure mode.
	On	Turns on continuous distance measure mode.

Field	Option	Description
<Prism Type:>	TrueZero	CPR111 Builder Prism, True-Zero Offset
	JpMini	Sliding Mini Prism
	Mini	Leica Mini Prism
	Round	Standard Leica Prism
	Flat Prism	CPR105 Flat Prism
	Tape	Reflective Tape
	User	User can define his own prism.
<Prism Const.:>		Entry of a user specific prism constant in [mm].
<hr:>		Entry of reflector height.

12.2

PPM


Description

This option enables the entry of a scale factor. Measured values and coordinates are corrected with the PPM parameter.



Access step-by-step

Descriptions apply only to Builder 400 and 500.

1. Make sure that **EDM Settings** is active.
 2. Press  for approximately 5 seconds.
 3. Enter the PPM parameter.
 4. Accept with **OK**.
-

Example of PPM
screen

Enter scale factor !

Scale factor: 1.000060

Scale ppm :

PPM=0

To set PPM parameter to zero.


OK

To accept parameter

Field	Description
<Scale factor:>	Calculated scale factor.
<Scale ppm:>	Entry of PPM value to calculate scale factor.


Atmospheric correction °C

Atmospheric correction in ppm with °C, mb, H (metres) at 60% relative humidity



Atmospheric correction °F

Atmospheric correction in ppm with °F, inch Hg, H (feet) at 60% relative humidity



13 System Info and Instrument Protection

13.1 System Info

Description



The System Info is used for:

- checking system and software information
- performing the calibrations of the instrument errors



Descriptions apply in general to all Builder models. Available options depend on the model.

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Make sure that **THEO** mode is active.
3. Press  for approximately 5 seconds.

Example of a
system info screen


```
SYSTEM INFO
Battery      :      80%
Instr. Temp. :      25 °C
Serial Nr.   :      777888
Instr. Type  :      500 (|)
Language     :      English (|)
Lang. Dlg.   :      Off (|)
CALIBR      PIN      SW Info
```

CALIBR To access the calibration routine. Refer to chapter "14 Check & Adjust".

PIN To access PIN code settings.

SW Info To access software information.

Field	Description
<Battery:>	Remaining battery power (for example 80%).
<Instr.Temp.:>	Measured instrument temperature in ° C.
<Serial Nr.:>	Serial number of the instrument.

Field	Description
<Instr.Type:>	<p>An alternative instrument type can be selected to reduce the software functionality, for example for demonstration purpose.</p> <p>For Builder 500 the instrument type 400, 300, 200 and 100 may be chosen as an alternative.</p> <p>For Builder 400 the instrument type 100 may be chosen as an alternative.</p> <p>For Builder 300 the instrument type 200 and 100 may be chosen as an alternative.</p> <p>For Builder 200 the instrument type 100 may be chosen as an alternative.</p> <p>For Builder 100 is this choice not available.</p> <p> The setting can be reversed.</p>
<Language:>	The current loaded language(s) are shown.
<Lang.Dlg:>	<p>If two or more languages are loaded onto the instrument a dialog to choose the language can be shown directly after switching on the instrument.</p> <p><On> The language dialog is shown as startup dialog.</p> <p><Off> The language dialog is not shown as startup dialog.</p>


13.2

Instrument Protection (PIN)

Description


The instrument can be protected by a **Personal Identification Number**. If the PIN protection is activated, the instrument will always prompt for a PIN code entry after starting up. As soon as the PIN was activated the access to the PIN code settings requires the PIN. If a wrong PIN has been typed in five times, a **Personal UnbloCking** code is required which can be found on the instrument delivery papers. If the PUK code was entered correctly, the PIN code is set to default value "0" and the PIN protection is deactivated.

Activate PIN code step-by-step


1. Turn on the instrument by pressing the  key.
2. Make sure that **THEO** mode is active.
3. Press **ESC** for approximately 5 seconds.
4. Press **PIN** to access PIN code settings.
5. Activate PIN by setting **<Use PIN-Code>: On**.
6. Enter your desired personal PIN Code (max. 6 character numeric) in **<New PIN-Code>:**.
7. Accept with **OK**.

Now the instrument is protected against unauthorized use. After switching on the instrument or re-enter in the PIN settings the PIN code entry is necessary.

**Deactivate PIN
code step-by-step**

1. Turn on the instrument by pressing the  key.
2. Make sure that **THEO** mode is active.
3. Press **ESC** for approximately 5 seconds.
4. Enter your personal PIN in **<PIN-CODE>:**.
5. Accept with **OK**.
6. Deactivate PIN by setting **<Use PIN-Code>: Off**.
7. Accept with **OK**.

Now the instrument is not protected anymore against unauthorized use.

**Example of a PIN
code settings
screen**

PIN-CODE SETTINGS

Use PIN-Code: On

New PIN-Code: 123456

OK

To accept settings.

Field	Option	Description
<Use PIN-Code:>	On Off	To activate PIN-code. To deactivate PIN-code.
<New PIN-Code:>		To enter your personal PIN-code (max. 6 character numeric).


13.3

Software Upload

Description

To load the application software or an additional language, connect the instrument to Leica's Construction Data Manager via the serial interface or USB cable and load using **Tools - Software Upload**. Refer to the Construction Data Manager help for further information. For instruments fitted with a Communication side cover, the software can be loaded via USB memory stick. This process is described below.

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Make sure that **THEO** mode is active.
3. Press the **ESC** key for approximately 5 seconds.
4. Press the **SW/LANG** button to get to the next step.



Never disconnect the power supply during the system upload process. The battery must be at least at 75% capacity before commencing the upload.

Loading firmware and languages step-by-step


1. To load firmware and languages: Select **Firmware & Language**.
The **Select File** screen will appear.
To load only languages: Select **Languages** and skip to step 4.
 2. Select the firmware file from the **System** folder on the USB memory stick.
All firmware and language files must be stored in the **System** folder to be transferred to the instrument.
 3. Press **OK**.
The **Upload Languages** screen will appear displaying all language files in the **System** folder on the USB memory stick.
 4. Select **Yes** or **No** for a language file to be uploaded. At least one language must be set to **Yes**.
 5. Press **OK**.
 6. Press **Yes** on the power warning message to proceed and upload the firmware and/or selected languages.
- Once successfully loaded, the system will automatically shutdown and restart.
-

13.4 Maintenance Key Upload

Description

To fully activate hardware functionality, onboard applications and maintenance contracts, licence keys may be required on the instrument. For all instruments, licence keys can be manually entered or up-loaded via Construction Data Manager. For instruments fitted with a Communication side cover licence keys can also be uploaded via a USB memory stick.

Access step-by-step

1. Turn on the instrument by pressing the  key.
2. Make sure that **THEO** mode is active.
3. Press the **ESC** key for approximately 5 seconds.
4. Press the **SW info** button to get into the Software Info menu.
5. Press the **MAIN.K** button to get to the next step.



Never disconnect the power supply during the system upload process. The battery must be at least at 75% capacity before commencing the upload.

Loading maintenance key file step-by-step

1. To load maintenance key file: In the **Enter license key** menu, select the method **Upload key file**.
The license key file must be stored in the **System** folder to be transferred to the instrument.
 2. Press **OK**.
- Once successfully loaded, the instrument will show a message of completion.
-

14 Check & Adjust

14.1 Overview

Description

Leica instruments are manufactured, assembled and adjusted to the best possible quality. Quick temperature changes, shock or stress can cause deviations and decrease the instrument accuracy. It is therefore recommended to check and adjust the instrument from time to time. This can be done in the field by running through specific measurement procedures. The procedures are guided and have to be followed carefully and precisely as described in the following chapters. Some other instrument errors and mechanical parts can be adjusted mechanically.

Electronic adjustment

The following instrument errors can be checked and adjusted electronically:

- l, t Compensator longitudinal and transversal index errors
- i Vertical index error, related to the standing axis
- c Hz collimation error, also called line of sight error

Every angle measured in the daily work is corrected automatically if the compensator and the Hz-correction are activated.

Mechanical adjustment

The following instrument parts can be adjusted mechanically:

- Circular level on instrument and tribrach
 - Laser plummet
 - Screws on tripod
 - Visible red laser beam for Builder 200 or higher. Only Leica Geosystems authorized service workshops are entitled to adjust these products.
 - Vertical line of the reticule for Builder 100.
-




During the manufacturing process, the instrument errors are carefully determined and set to zero. As mentioned above, these errors can change and it is highly recommended to redetermine them in the following situations:

- Before the first use
 - Before every high precision survey
 - After rough or long transportations
 - After long working periods
 - After long storage periods
 - If the temperature difference between current environment and the temperature at the last calibration is more than 20°C
-

14.2

Preparation



Before determining the instrument errors, the instrument has to be levelled-up using the electronic level.
The tribrach, the tripod and the underground should be very stable and secure from vibrations or other disturbances.



The instrument should be protected from direct sunlight in order to avoid thermal warming.
It is also recommended to avoid strong heat shimmer and air turbulence. The best conditions are usually early in the morning or with overcast sky.




Before starting to work, the instrument has to become acclimatised to the ambient temperature. Approximately two minutes per °C of temperature difference from storage to working environment but at least 15 min should be taken into account.


14.3

Combined Adjustment of Hz Collimation (c), Vertical Index (i) and Compensator Index (l, t) Errors

Description


The combined adjustment procedure determines the following instrument errors in one process:


Type	Description	Diagram
c	The Hz collimation error (c) is also called line of sight error. It is caused by the deviation between the optical line of sight, which means the direction in which the crosshairs points and the line perpendicular to the tilting axis. This error affects all Hz readings and increases with steep sight-ings.	 <p>a) Tilting axis b) Line perpendicular to tilting axis c) Hz collimation error (c), also called line of sight error d) Line of sight</p>

Type	Description	Diagram
i	<p>A vertical index error (i) exists, if the 0° mark of the vertical circle reading doesn't coincide with the mechanical vertical axis of the instrument, also called standing axis. The vertical index error (i) is a constant error that affects all vertical angle readings.</p>	 <p>a) Mechanical vertical axis of the instrument, also called standing axis b) Axis perpendicular to the vertical axis c) $V = 90^\circ$ reading d) Vertical index error</p>
l, t	Compensator longitudinal (l) and transversal (t) index errors.	

Combined adjustment procedure step-by-step

The following table explains the most common settings. Refer to the stated chapter for more information on screens.


1. Turn on the instrument by pressing the  key.
2. Level up the instrument.
Refer to "5.2 Instrument Setup" for more information.
3. Make sure that **THEO** mode is active.
4. Press **ESC** for approximately 5 seconds until **SYSTEM INFO** is active.
5. Press **CALIBR.**
6. Press **NEW.**
- 7.



Aim with the telescope accurately at a target at a distance of about 100 m. The target must be positioned within $\pm 5^\circ$ of the horizontal plane.

8. Press **MEASURE** to measure the target


9.



Aim with the telescope accurately at a target at a distance of about 100 m. The target must be positioned within $\pm 5^\circ$ of the horizontal plane.

10. Press **MEASURE** to measure the same target again and to calculate the instrument errors.
The old and new adjustment results are shown.
 11. Press **SET** to set new adjustment data.
OR
Press **ESC** to quit without setting the new adjustment data.
-


Set Hz correction
(c)

Field	Option	Field Description
<Hz-Correction:>	On	The horizontal angles are corrected for the line of sight and if <Compensator: On> transversal tilt errors.
	Off	Horizontal angles are not corrected.  After switching on the instrument, the setting is automatically reset to <Hz-Correction: On >.

14.4

Adjustment of the Circular Level

On the instrument
step-by-step




1. Level up the instrument in advance with the electronic level, assuming that the electronic level is correctly adjusted.
2. The bubble must be centered. If it extends beyond the circle, use the allen keys supplied to centre it with the adjustment screws. Turn the instrument slowly 200 gon (180°). Repeat the adjustment procedure if the bubble does not stay centered.



After the adjustment, no screw shall be loose.

On the tribrach step-by-step



1. Level up the instrument with the electronic level, assuming that the electronic level is correctly adjusted. Refer to "5.2 Instrument Setup" for more information. Then remove it from the tribrach.
2. The bubble of the tribrach must be centered. If it extends beyond the circle, use the adjusting pin in conjunction with the two cross headed adjustment screws to centre it.



After the adjustment, no screw shall be loose.


14.5


Adjustment of the Laser Plummet



The laser plummet is located in the vertical axis of the instrument. Under normal conditions of use, the laser plummet does not need adjusting. If an adjustment is necessary due to external influences, the instrument has to be returned to any Leica Geosystems authorized service workshop.

Inspecting laser plummet step-by-step



1. Setup the instrument on a tripod (1) approximately 1.5 m above ground.
2. Turn on the instrument by pressing the  key.

3. Level up the instrument with the electronic level. Refer to "5.2 Instrument Setup" for more information.



Inspection of the laser plummet should be carried out on a bright, smooth and horizontal surface, such like a sheet of paper.

4. Mark the centre of the red dot on the ground (2).

5. Slowly turn the instrument through 360° , carefully observing the movement of the red laser dot (3).




The maximum diameter of the circular movement described by the centre of the laser point should not exceed 3 mm at a distance of 1.5 m.

6. If the centre of the laser dot describes a perceptible circular movement or moves more than 3 mm away from the point which was first marked, an adjustment may be required. Inform your nearest Leica Geosystems authorized service workshop. Depending on brightness and surface, the diameter of the laser dot can vary. At a distance of 1.5 m it is about 2.5 mm.

14.6

Service of the Tripod

Service tripod step-by-step



The connections must be firm and tight.

1. Moderately tighten the allen screws with the allen key supplied with the tripod.
2. Tighten articulated joints just enough to keep the tripod legs open when lifting the tripod of the ground.
3. Tighten the screws of the tripod legs.

14.7**Inspection of the Red Laser Beam, for Builder 200 or higher**

General

The red laser beam used for measuring is arranged coaxially with the line of sight of the telescope, and emerges from the objective port. If the instrument is well adjusted, the red measuring beam coincides with the visual line of sight. External influences such as shock, stress or large temperature fluctuations can displace the red measuring beam relative to the line of sight.



The direction of the beam should be inspected from time to time, because an excessive deviation of the laser beam from the line of sight can result in imprecise distance measurements.

Inspecting of the red laser beam step-by-step




1. Set up the provided CPR105 Flat prism between 5 m and 20 m with the reflective tape side facing the instrument.
 2. Align the instrument crosshairs to the centre of the Flat prism.
 3. Switch on the red laser beam by activating the **Laserpointer** function in Configuration Mode (except Builder 400).
 4. Without using the telescope inspect the position of the red laser dot on the Flat prism.
Look at the Flat prism from just above the telescope or from just to the side of it.
 5. If the dot is within the inner printed circle the laser beam is within tolerance. If it is outside it is recommended to have the laser beam realigned by a Leica Geosystems authorized service workshop.
-

14.8

Adjustment of the Vertical Line of the Reticule, for Builder 100

Inspection step-by-step




1. Aim on any point in the centre of the reticule.
2. With the vertical drive move the instrument upwards to the edge of the range of vision.



If the point moves along the vertical line no adjustment is necessary.

Adjusting step-by-step



1. If the point does not move along the vertical line remove cover of adjusting screws on the eyepiece.
 2. With the help of the supplied tool loosen all four adjusting screws by the same amount.
 3. Turn the reticle until the vertical line is aligned with the point.
 4. Subsequently, tighten the adjusting screws and repeat the checking procedure until adjustment is correct.
-

15 Care and Transport

15.1 Transport

Transport in the field

When transporting the equipment in the field, always make sure that you

- either carry the product in its original transport container,
 - or carry the tripod with its legs splayed across your shoulder, keeping the attached product upright.
-

Transport in a road vehicle

Never carry the product loose in a road vehicle, as it can be affected by shock and vibration. Always carry the product in its transport container and secure it.

Shipping

When transporting the product by rail, air or sea, always use the complete original Leica Geosystems packaging, transport container and cardboard box, or its equivalent, to protect against shock and vibration.

Shipping, transport of batteries

When transporting or shipping batteries, the person in charge of the product must ensure that the applicable national and international rules and regulations are observed. Before transportation or shipping, contact your local passenger or freight transport company.

Field adjustment

After transport inspect the field adjustment parameters given in this user manual before using the product.

15.2

Storage

Product

Respect the temperature limits when storing the equipment, particularly in summer if the equipment is inside a vehicle. Refer to "18 Technical Data" for information about temperature limits.

Field adjustment

After long periods of storage inspect the field adjustment parameters given in this user manual before using the product.

Batteries

- **For all batteries**
 - Refer to "18.3 General Technical Data of the Instrument" for information about storage temperature range.
 - At the recommended storage temperature range, batteries containing a 10% to 50% charge can be stored for up to one year. After this storage period the batteries must be recharged.
 - Remove batteries from the product and the charger before storing.
 - After storage recharge batteries (NiMH) before using.
 - Protect batteries from damp and wetness. Wet or damp batteries must be dried before storing or use.

- **For Li-Ion batteries**
 - Batteries can be stored within -40°C to $+55^{\circ}\text{C}$ / -40°F to $+131^{\circ}\text{F}$ temperature range, however a storage temperature range of -20°C to $+30^{\circ}\text{C}$ / -4°F to $+88^{\circ}\text{F}$ in dry environment is recommended to minimize self-discharging of the battery.
 - **For NiMH batteries**
 - A storage temperature range of 0°C to $+20^{\circ}\text{C}$ / $+32^{\circ}\text{F}$ to $+68^{\circ}\text{F}$ in dry environment is recommended to minimize self-discharging of the battery.
-

15.3

Cleaning and Drying

Objective, eyepiece and prisms


- Blow dust off lenses and prisms.
 - Never touch the glass with your fingers.
 - Use only a clean, soft, lint-free cloth for cleaning. If necessary, moisten the cloth with water or pure alcohol. Do not use other liquids; these may attack the polymer components. For cleaning the Flat prism pure alcohol is not allowed.
-

Fogging of prisms

Reflector prisms that are cooler than the ambient temperature tend to fog. It is not enough simply to wipe them. Keep them for some time inside your jacket or in the vehicle to allow them to adjust to the ambient temperature.

Damp products

- Dry the product, the transport container, the foam inserts and the accessories at a temperature not greater than 40°C / 104°F and clean them.
- Do not repack until everything is completely dry.
- Always close the transport container when using in the field.



Cables and plugs

Keep plugs clean and dry. Blow away any dirt lodged in the plugs of the connecting cables.

16 Construction Data Manager

16.1 Overview

Description

Construction Data Manager is supposed to support the exchange of Leica Builder data with the PC, using a Windows® application. It can also be used for data import and export, data handling and upload of firmware, languages and key files.

16.2 Installation

Installing Construction Data Manager

1. Insert the instrument's CD into your PC's CD drive.
After some seconds, a welcome screen will pop up. Please follow the on-screen instructions and skip the following two steps.
 2. If the welcome screen will not show up, use the Windows Explorer to navigate to your CD drive.
 3. Open the folder **Software** and double-click on the Construction Data Manager file to start the setup.
-

Microsoft Active-Sync for Microsoft Windows 2000/XP

If you want to connect your Windows 2000/XP PC with a USB cable to your Builder, you have to install Microsoft ActiveSync 4.5 (or later) first. You can find it on the instrument's CD in the subfolder **Tools, ActiveSync** or you can download the latest version directly from Microsoft on the following web page:

<http://www.microsoft.com/windowsmobile/en-us/help/synchronize/activesync-download.msp>

Microsoft Windows Mobile Manager for Windows Vista

If you want to connect your Windows Vista PC with a USB cable to your Builder, you have to install Microsoft Windows Mobile Manager first.

You can find it on the instrument's CD in the subfolders **Tools, Windows Mobile Manager** or you can download the latest version directly from Microsoft on the following web page:

<http://www.microsoft.com/windowsmobile/en-us/help/synchronize/device-center-download.msp>

16.3

Connection

Serial cable and COM Parameters

For data and software transfer you can use either the GEV102 serial cable or the GEV189 USB to serial cable. Please refer to the following COM settings for the different Builder models which have to be set in Communication Parameters in the Construction Data Manager.

Model	COM setting			
	Baud rate	Parity	Data bits	Stop bits
Builder 200 series	38400	NONE	8	1
Builder 300 series	57600	NONE	8	1

Model	COM setting			
	Baud rate	Parity	Data bits	Stop bits
Builder 400 series	115200	NONE	8	1
Builder 500 series	115200	NONE	8	1

Using USB cable connection for the first time (only for Builder 300 or higher)

1. Make sure that you have installed Microsoft ActiveSync (for Windows XP) or Microsoft Windows Mobile Manager (for Windows Vista) on your PC. Refer to "16.2 Installation".
2. Turn on the Builder and open the Communication side cover.
3. Plug the Mini USB connector of the GEV223 USB cable into the Mini USB port of the instrument.
4. Plug the standard USB connector of the GEV223 USB cable into a free USB port of your PC.
Microsoft ActiveSync/Windows Mobile Manager will start and after some seconds a window will pop up and ask you whether you want to make a new Partnership.
5. Select **YES** and click **NEXT**.
6. In the **Select number of Partnerships** window, select **YES** and click **NEXT**.
7. In the **Synchronization Settings**, just click **NEXT**.
8. Confirm the **Setup Complete** screen with a click on **FINISH**.

The connection is properly established when you see a green icon with two white arrows in the Microsoft Windows Tray next to the clock.

After the connection has been properly established, it is normally not necessary to repeat all the previous steps. You only have to connect the instrument to the PC using the USB cable (steps 2.-4.) and the connection will be established automatically in the background.

Disconnecting USB cable connection

For disconnecting the USB cable connection, first turn off the instrument and then remove the connectors. This avoids problems with the Microsoft ActiveSync tool.

16.4

Online help

Description

For further information about and hints on the usage of Construction Data Manager refer to the Online Help. It can be accessed by clicking on **? / Help** in the **Main menu**.

17 Safety Directions

17.1 General

Description

The following directions should enable the person responsible for the product, and the person who actually uses the equipment, to anticipate and avoid operational hazards.

The person responsible for the product must ensure that all users understand these directions and adhere to them.

17.2

Intended Use

Permitted use

- Measuring horizontal and vertical angles.
 - Measuring distances.
 - Recording measurements.
 - Computing by means of software.
 - Visualizing the aiming direction and vertical axis.
 - Data communication with external appliances.
-

Adverse use

- Use of the product without instruction.
- Use outside of the intended limits.
- Disabling safety systems.
- Removal of hazard notices.
- Opening the product using tools, for example screwdriver, unless this is specifically permitted for certain functions.
- Modification or conversion of the product.
- Use after misappropriation.
- Use of products with obviously recognizable damages or defects.
- Use with accessories from other manufacturers without the prior explicit approval of Leica Geosystems.
- Aiming directly into the sun.

- Inadequate safeguards at the working site, for example when measuring on roads.
- Deliberate dazzling of third parties.
- Controlling of machines, moving objects or similar monitoring application without additional control- and safety installations.



Adverse use can lead to injury, malfunction and damage.

It is the task of the person responsible for the equipment to inform the user about hazards and how to counteract them. The product is not to be operated until the user has been instructed on how to work with it.

17.3

Limits of Use

Environment

Suitable for use in an atmosphere appropriate for permanent human habitation: not suitable for use in aggressive or explosive environments.



Danger

Local safety authorities and safety experts must be contacted before working in hazardous areas, or in close proximity to electrical installations or similar situations by the person in charge of the product.

17.4

Responsibilities

Manufacturer of the product

Leica Geosystems AG, CH-9435 Heerbrugg, hereinafter referred to as Leica Geosystems, is responsible for supplying the product, including the user manual and original accessories, in a completely safe condition.

Manufacturers of non Leica Geosystems accessories

The manufacturers of non Leica Geosystems accessories for the product are responsible for developing, implementing and communicating safety concepts for their products, and are also responsible for the effectiveness of those safety concepts in combination with the Leica Geosystems product.

Person in charge of the product

The person in charge of the product has the following duties:

- To understand the safety instructions on the product and the instructions in the user manual.
- To be familiar with local regulations relating to safety and accident prevention.
- To inform Leica Geosystems immediately if the product and the application becomes unsafe.
- To ensure that the national laws, regulations and conditions for the operation of radio transmitters are respected.



Warning

The person responsible for the product must ensure that it is used in accordance with the instructions. This person is also accountable for the training and the deployment of personnel who use the product and for the safety of the equipment in use.

17.5

Hazards of Use

Warning

The absence of instruction, or the inadequate imparting of instruction, can lead to incorrect or adverse use, and can give rise to accidents with far-reaching human, material, financial and environmental consequences.

Precautions:

All users must follow the safety directions given by the manufacturer and the directions of the person responsible for the product.

Caution

Watch out for erroneous measurement results if the product has been dropped or has been misused, modified, stored for long periods or transported.

Precautions:

Periodically carry out test measurements and perform the field adjustments indicated in the user manual, particularly after the product has been subjected to abnormal use and before and after important measurements.

 **Danger**

Because of the risk of electrocution, it is very dangerous to use poles and extensions in the vicinity of electrical installations such as power cables or electrical railways.

Precautions:

Keep at a safe distance from electrical installations. If it is essential to work in this environment, first contact the safety authorities responsible for the electrical installations and follow their instructions.

 **Warning**

If the product is used with accessories, for example masts, staffs, poles, you may increase the risk of being struck by lightning.

Precautions:

Do not use the product in a thunderstorm.

 **Caution**

Be careful when pointing the product towards the sun, because the telescope functions as a magnifying glass and can injure your eyes and/or cause damage inside the product.

Precautions:

Do not point the product directly at the sun.

 **Warning**

During dynamic applications, for example stakeout procedures there is a danger of accidents occurring if the user does not pay attention to the environmental conditions around, for example obstacles, excavations or traffic.

Precautions:

The person responsible for the product must make all users fully aware of the existing dangers.

 **Warning**

Inadequate securing of the working site can lead to dangerous situations, for example in traffic, on building sites, and at industrial installations.

Precautions:




Always ensure that the working site is adequately secured. Adhere to the regulations governing safety and accident prevention and road traffic.

 **Warning**

If computers intended for use indoors are used in the field there is a danger of electric shock.

Precautions:

Adhere to the instructions given by the computer manufacturer with regard to field use in conjunction with Leica Geosystems products.

-
-  **Caution** If the accessories used with the product are not properly secured and the product is subjected to mechanical shock, for example blows or falling, the product may be damaged or people may sustain injury.
- Precautions:**
When setting-up the product, make sure that the accessories are correctly adapted, fitted, secured, and locked in position.
Avoid subjecting the product to mechanical stress.
-
-  **Caution** During the transport, shipping or disposal of batteries it is possible for inappropriate mechanical influences to constitute a fire hazard.
- Precautions:**
Before shipping the product or disposing of it, discharge the batteries by running the product until they are flat.
When transporting or shipping batteries, the person in charge of the product must ensure that the applicable national and international rules and regulations are observed. Before transportation or shipping contact your local passenger or freight transport company.
-
-  **Warning** Using a battery charger not recommended by Leica Geosystems can destroy the batteries. This can cause fire or explosions.
- Precautions:**
Only use chargers recommended by Leica Geosystems to charge the batteries.
-

 **Warning**

Batteries not recommended by Leica Geosystems may be damaged if charged or discharged. They may burn and explode.

Precautions:

Only charge and discharge batteries recommended by Leica Geosystems.

 **Warning**

High mechanical stress, high ambient temperatures or immersion into fluids can cause leakage, fire or explosions of the batteries.

Precautions:

Protect the batteries from mechanical influences and high ambient temperatures. Do not drop or immerse batteries into fluids.

 **Warning**

If battery terminals come in contact with jewellery, keys, metallised paper or other metals, short circuited battery terminals can overheat and cause injury or fire, for example by storing or transporting in pockets.

Precautions:

Make sure that the battery terminals do not come into contact with metallic objects.

 **Warning**

If the product is improperly disposed of, the following can happen:

- If polymer parts are burnt, poisonous gases are produced which may impair health.
- If batteries are damaged or are heated strongly, they can explode and cause poisoning, burning, corrosion or environmental contamination.
- By disposing of the product irresponsibly you may enable unauthorized persons to use it in contravention of the regulations, exposing themselves and third parties to the risk of severe injury and rendering the environment liable to contamination.
- Improper disposal of silicone oil may cause environmental contamination.

Precautions:

The product must not be disposed with household waste.

Dispose of the product appropriately in accordance with the national regulations in force in your country.

Always prevent access to the product by unauthorized personnel.

Product specific treatment and waste management information can be downloaded from the Leica Geosystems home page at <http://www.leica-geosystems.com/treatment> or received from your Leica Geosystems dealer.

 **Warning**

Only Leica Geosystems authorized service workshops are entitled to repair these products.

17.6

Laser Classification

General

The following directions (in accordance with the state of the art - international standard IEC 60825-1 (2007-03) and IEC TR 60825-14 (2004-02)) provide instruction and training information to the person responsible for the product and the person who actually uses the equipment, to anticipate and avoid operational hazards.

The person responsible for the product must ensure that all users understand these directions and adhere to them.

Products classified as laser class 1, class 2 and class 3R do not require

- laser safety officer involvement,
- protective clothes and eyewear,
- special warning signs in the laser working area

if used and operated as defined in this user manual due to the low eye hazard level.

Products classified as laser class 2 or class 3R may cause dazzle, flash-blindness and afterimages, particularly under low ambient light conditions.

17.6.1 Integrated Distancer, Measurements with Red Dot (for Builder 200 or higher)

General

As an alternative to the invisible laser, the EDM incorporated into the product produces a visible red laser beam which emerges from the telescope objective.

The laser product described in this section, is classified as laser class 3R in accordance with:

- IEC 60825-1 (2007-03): "Safety of laser products".
- EN 60825-1 (2007-10): "Safety of laser products".

Class 3R laser products:

Direct intrabeam viewing may be hazardous (low-level eye hazard), in particular for deliberate ocular exposure. The risk of injury for laser class 3R products is limited because of:

- a) unintentional exposure would rarely reflect worst case conditions of (e.g.) beam alignment with the pupil, worst case accommodation,
- b) inherent safety margin in the maximum permissible exposure to laser radiation (MPE)
- c) natural aversion behaviour for exposure to bright light for the case of visible radiation.

Description	Value
Maximum average radiant power	5.00 mW
Pulse duration	800 ps
Pulse repetition frequency	100 MHz - 150 MHz
Wavelength	650 nm - 690 nm
Beam divergence	0.2 mrad x 0.3 mrad
NOHD (Nominal Ocular Hazard Distance) @ 0.25s	80 m / 263 ft

 **Warning**

From a safety perspective class 3R laser products should be treated as potentially hazardous.

Precautions:

Prevent direct eye exposure to the beam. Do not direct the beam at other people.


 **Warning**

Potential hazards are not only related to direct beams but also to reflected beams aimed at reflecting surfaces such as prisms, windows, mirrors, metallic surfaces etc.

Precautions:

Do not aim at areas that are essentially reflective, such as a mirror, or which could emit unwanted reflections. Do not look through or beside the optical sight at prisms or reflecting objects when the laser is switched on, in laser pointer or distance measurement mode. Aiming at prisms is only permitted when looking through the telescope.

Labelling



a) Laser beam

.....

.....

.....

.....



.....

.....

.....

.....

.....




Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.



17.6.2 Integrated Distancer, Measurements with Prism (only Builder 400 and 500)

General

The EDM module built into the product produces a visible laser beam which emerges from the telescope objective.

The laser product described in this section is classified as laser class 1 in accordance with:



- IEC 60825-1 (2007-03): "Safety of laser products".
- EN 60825-1 (2007-10): "Safety of laser products".

Class 1 laser products are safe under reasonably foreseeable conditions of operation and are not harmful to the eyes provided that the products are used and maintained in accordance with this user manual.

Description	Value
Maximum average radiant power	0.33 mW
Pulse duration	800 ps
Pulse repetition frequency	100 MHz - 150 MHz
Wavelength	650 nm - 690 nm

Labelling

.....
.....
.....
.....
.....




Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Class 1 Laser Product
according to IEC 60825-1
(2007-03)



a) Laser beam

17.6.3

Laser Plummet

General

The laser plummet built into the product produces a visible red laser beam which emerges from the bottom of the product.

The laser product described in this section, is classified as laser class 2 in accordance with:

- IEC 60825-1 (2007-03): "Safety of laser products".
- EN 60825-1 (2007-10): "Safety of laser products".

Class 2 laser products:

These products are safe for momentary exposures but can be hazardous for deliberate staring into the beam.


Description	Value
Maximum average radiant power	1.00 mW
Pulse duration	0-100%
Pulse repetition frequency	1 kHz
Wavelength	620 nm - 690 nm

 **Warning**

From a safety perspective class 2 laser products are not inherently safe for the eyes.

Precautions:

Avoid staring into the beam or pointing the beam at other people.



- a) Laser beam
- b) Exit for laser beam

17.7

Electromagnetic Compatibility EMC

Description

The term Electromagnetic Compatibility is taken to mean the capability of the product to function smoothly in an environment where electromagnetic radiation and electrostatic discharges are present, and without causing electromagnetic disturbances to other equipment.



Warning

Electromagnetic radiation can cause disturbances in other equipment.

Although the product meets the strict regulations and standards which are in force in this respect, Leica Geosystems cannot completely exclude the possibility that other equipment may be disturbed.



Caution

There is a risk that disturbances may be caused in other equipment if the product is used in conjunction with accessories from other manufacturers, for example field computers, personal computers, two-way radios, non-standard cables or external batteries.

Precautions:

Use only the equipment and accessories recommended by Leica Geosystems. When combined with the product, they meet the strict requirements stipulated by the guidelines and standards. When using computers and two-way radios, pay attention to the information about electromagnetic compatibility provided by the manufacturer.

 **Caution**

Disturbances caused by electromagnetic radiation can result in erroneous measurements.

Although the product meets the strict regulations and standards which are in force in this respect, Leica Geosystems cannot completely exclude the possibility that the product may be disturbed by very intense electromagnetic radiation, for example, near radio transmitters, two-way radios or diesel generators.

Precautions:

Check the plausibility of results obtained under these conditions.

 **Warning**

If the product is operated with connecting cables attached at only one of their two ends, for example external supply cables, interface cables, the permitted level of electromagnetic radiation may be exceeded and the correct functioning of other products may be impaired.

Precautions:

While the product is in use, connecting cables, for example product to external battery, product to computer, must be connected at both ends.

Bluetooth

Use of product with Bluetooth:

**Warning**

Electromagnetic fields can cause disturbances in other equipment, in installations, in medical devices, for example pacemakers or hearing aids and in aircraft. It can also affect humans and animals.

Precautions:

Although the product meets in combination with radio or digital cellular phone devices recommended by Leica Geosystems the strict regulations and standards which are in force in this respect, Leica Geosystems cannot completely exclude the possibility that other equipment may be disturbed or that humans or animals may be affected.

- Do not operate the product with radio or digital cellular phone devices in the vicinity of filling stations or chemical installations, or in other areas where an explosion hazard exists.
 - Do not operate the product with radio or digital cellular phone devices near to medical equipment.
 - Do not operate the product with radio or digital cellular phone devices in aircraft.
-

17.8

FCC Statement, Applicable in U.S.

Applicability

The greyed paragraph below is only applicable for Builder instruments without Bluetooth.

Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning


Changes or modifications not expressly approved by Leica Geosystems for compliance could void the user's authority to operate the equipment.

Labelling


.....
.....
.....
.....
.....



Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.
This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.



Labelling internal battery GEB211, GEB221




Builder_085

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


UL LISTED
ITE Accessory
E179078 . 70YL

Labelling GKL212



Type: GKL212

Art.No.:

.....

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

18 Technical Data

18.1 Angle Measurement

Accuracy

All Builder models, type	Standard deviation Hz, V, ISO 17123-3		Display least count	
	["]	[mgon]	["]	[mgon]
09	9	2.8	1	1
06	6	1.8	1	0.1
05	5	1.5	1	0.1
03*	3	1	1	0.1

* Type 03 is only available for the Builder 500.

Characteristics

Absolute, continuous.

18.2

Distance Measurement

Reflectorless
standard range

Kodak Gray Card	Type	Range D		Range E		Range F	
		[m]	[ft]	[m]	[ft]	[m]	[ft]
White side, 90 % reflective	Builder 200	60	200	80	260	>80	>260
	Builder 300	80	260	120	390	>120	>390
	Builder 400	15	50	15	50	15	50
	Builder 500	150	490	250	820	>250	>820
Grey side, 18 % reflective	Builder 200	30	100	50	160	>50	>160
	Builder 300	50	160	70	230	>70	>230
	Builder 400	15	50	15	50	15	50
	Builder 500	100	330	150	490	>200	>660

Reflector range (red dot)	Range of measurement Flat prism CPR105:	1.5 m to 250 m
	Display unambiguous:	Up to 250 m

Type	CPR105	Range D		Range E		Range F	
		[m]	[ft]	[m]	[ft]	[m]	[ft]
Standard	Reflective tape	150	490	170	560	170	560
Standard	Cat-eye	250	820	250	820	250	820

Atmospheric conditions	D:	Object in strong sunlight, severe heat shimmer
	E:	Object in shade, sky overcast
	F:	Underground, night and twilight

Accuracy

Standard measuring	Standard deviation, ISO 17123-4	Measure time, typical [s]
Standard Reflectorless	3 mm + 2 ppm	3.0
CPR105 Flat prism (Cat-eye)	5 mm + 2 ppm	< 2
CPR105 Flat prism (Reflective tape)	3 mm + 2ppm	< 2

Standard measuring	Standard deviation, ISO 17123-4	Measure time, typical [s]
Tracking	5 mm + 2 ppm	1.0

Object in shade, sky overcast.

Beam interruptions, severe heat shimmer and moving objects within the beam path can result in deviations of the specified accuracy.

The display resolution is 1 mm.

Reflector range (prism mode)

Range of measurement: 1.5 m to 3500 m

Type	Range 1		Range 2		Range 3	
	[m]	[ft]	[m]	[ft]	[m]	[ft]
CPR111 Builder prism, true-zero offset	450	1500	800	2600	1000	3500
Round prism	1800	6000	3000	10000	3500	12000



The range on the round prism is only achievable with the upgraded distance measurement. Otherwise the specifications of the CPR111 are valid (max. 500 m). Please refer to "5.5 Distance Measurement".

Atmospheric conditions	1:	Strong haze, visibility 5km; or strong sunlight, severe heat shimmer
	2:	Light haze, visibility about 20km; or moderate sunlight, slight heat shimmer
	3:	Overcast, no haze, visibility about 40km; no heat shimmer

Accuracy

Standard measuring	Standard deviation, ISO 17123-4	Measure time, typical [s]
Prism	2 mm + 2 ppm	< 1
Tracking	5 mm + 2ppm	< 0.3

Beam interruptions, severe heat shimmer and moving objects within the beam path can result in deviations of the specified accuracy.

Characteristics

Measuring system:	System analyser basis 100 MHz - 150 MHz
Type:	Coaxial, visible red laser
Carrier wave:	658 nm

Laser dot size

Distance [m]	Laser dot size, approximately [mm]
at 20	10 x 12
at 50	13 x 21
at 250	38 X 85

18.3

General Technical Data of the Instrument

Telescope

Type	Builder 100	Builder 200 or higher
Magnification	30 x	30 x
Clear objective diameter	40 mm	40 mm
Focusing	1.6 m/5.2 ft to infinity	1.7 m/5.6 ft to infinity
Field of view	1°21'/1.50 gon 2.4 m at 100 m	1°30'/1.66 gon 2.6 m at 100 m

Compensator

Type	Setting accuracy		Setting range	
	["]	[mgon]	[']	[gon]
All Builder models	2	0.7	4	0.07

Level



Circular level sensitivity: 6'/2 mm
Electronic level resolution: 6" (=20^{cc})

Control unit	Display:	280 x 160 pixels, monochrome, graphics capable LCD, illumination
	Keyboard:	7 keys / 20 keys (only Builder 400 and 500)
	Angle Display:	360°", 360° decimal, 400 gon, 6400 mil, V %
	Distance Display:	m, ft int, ft us, ft inch 1/16 (except Builder 100)
	Position:	In both faces, face two is optional

**Instrument Ports,
Builder 200 or
higher**

Name	Description
RS232	5 pin LEMO-0 for power, communication, data transfer. This port is located at the base of the instrument.
USB host port	USB memory stick port for data transfer (only for Builder 300 or higher).
USB device port	Cable connections from USB devices for communication and data transfer (only for Builder 300 or higher).
Bluetooth	Bluetooth connections for communication and data transfer (only for Builder 500).

Instrument Dimensions



Weight

Instrument:	3.3 - 4.1 kg
Tribrach:	0.8 kg
Battery GEB211:	0.1 kg
Battery GEB221:	0.2 kg

**Recording,
Builder 300, 400
and 500 only**

Data can be recorded into internal memory.

Type	Capacity [MB]	Number of points
Internal memory (Builder 300)	2	15,000
Internal memory (Builder 400 and 500)	10	50,000

Laser plummet

Type: Visible red laser class 2
 Location: In vertical axis of instrument
 Accuracy: Deviation from plumbline:
 1.5 mm at 1.5 m instrument height
 Diameter of laser point: 2.5 mm at 1.5 m instrument height

Drives

Type: Endless horizontal and vertical drives

**Power, Builder 200
or higher**

External supply voltage: Nominal voltage 12.8 V DC, Range 11.5 V-13.5 V

Battery GEB211

Type:	Li-Ion
Voltage:	7.4 V
Capacity:	2.2 Ah
Operating time*:	approximately 10 hours

* Based on a single measurement every 30 seconds at 25°C. Operating time may be shorter if battery is not new.

Battery GEB221

Type:	Li-Ion
Voltage:	7.4 V
Capacity:	4.4 Ah
Operating time*:	approximately 20 hours

* Based on a single measurement every 30 seconds at 25°C. Operating time may be shorter if battery is not new.

**External battery,
Builder 200 or
higher**

Type:	NiMH
Voltage:	12 V
Capacity:	GEB171: 9.0 Ah
Typical operating time:	20 - 24 h

Environmental specifications

Temperature

Type	Operating temperature [°C]	Storage temperature [°C]
Builder	-20 to +50	-40 to +70
Battery	-20 to +50	-40 to +70
USB memory stick	-40 to +85	-50 to +95
Builder Arctic	-30 to +50	-40 to +70

Protection against dust, sand and water

Type	Protection
Builder	IP55 (IEC 60529)

Humidity

Type	Protection
Builder	Max 95 % non condensing The effects of condensation are to be effectively counteracted by periodically drying out the instrument.

Reflectors

Type	Additive Constant [mm]
CPR105 Flat prism (Cat-eye)	0.0
CPR105 Flat prism (reflective tape)	0.0
Reflectorless	0.0
GZM28 reflective tape 60x60 mm	0.0
CPR111 Builder prism, true-zero offset	0.0

Automatic corrections

The following automatic corrections are made:

- Line of sight error
- Tilting axis error
- Earth curvature
- Compensator index error
- Vertical index error
- Refraction

18.4

Conformity to National Regulations

18.4.1

Products without Communication side cover

Conformity to national regulations



Hereby, Leica Geosystems AG, declares that the instrument is in compliance with the essential requirements and other relevant provisions of applicable European Directives. The declaration of conformity may be consulted at <http://www.leica-geosystems.com/ce>.

18.4.2

Products with Communication side cover

Conformity to national regulations

- FCC Part 15 (applicable in US).
- Hereby, Leica Geosystems AG, declares that the instrument with Communication side cover is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at <http://www.leica-geosystems.com/ce>.



Class 1 equipment according European Directive 1999/5/EC (R&TTE) can be placed on the market and be put into service without restrictions in any EEA Member state.

- The conformity for countries with other national regulations not covered by the FCC part 15 or European directive 1999/5/EC has to be approved prior to use and operation.
-

Frequency band

2402 - 2480 MHz

Output power

Bluetooth: 2.5 mW

Antenna

Type: Mono pole
Gain: +2 dBi

19 International Limited Warranty, Software License Agreement

International Limited Warranty

This product is subject to the terms and conditions set out in the International Limited Warranty which you can download from the Leica Geosystems home page at <http://www.leica-geosystems.com/internationalwarranty> or collect from your Leica Geosystems distributor. The foregoing warranty is exclusive and is in lieu of all other warranties, terms or conditions, express or implied, either in fact or by operation of law, statutory or otherwise, including warranties, terms or conditions of merchantability, fitness for a particular purpose, satisfactory quality and non-infringement, all of which are expressly disclaimed.

Software License Agreement

This product contains software that is preinstalled on the product, or that is supplied to you on a data carrier medium, or that can be downloaded by you online pursuant to prior authorization from Leica Geosystems. Such software is protected by copyright and other laws and its use is defined and regulated by the Leica Geosystems Software License Agreement, which covers aspects such as, but not limited to, Scope of the License, Warranty, Intellectual Property Rights, Limitation of Liability, Exclusion of other Assurances, Governing Law and Place of Jurisdiction. Please make sure, that at any time you fully comply with the terms and conditions of the Leica Geosystems Software License Agreement.

Such agreement is provided together with all products and can also be referred to and downloaded at the Leica Geosystems home page at <http://www.leica-geosystems.com/swlicense> or collected from your Leica Geosystems distributor.

You must not install or use the software unless you have read and accepted the terms and conditions of the Leica Geosystems Software License Agreement. Installation or use of the software or any part thereof, is deemed to be an acceptance of all the terms and conditions of such License Agreement. If you do not agree to all or some of the terms of such License Agreement, you may not download, install or use the software and you must return the unused software together with its accompanying documentation and the purchase receipt to the dealer from whom you purchased the product within ten (10) days of purchase to obtain a full refund of the purchase price.

Index

A

Abbreviations	14	Measure & Descriptor	107
Accuracy	234, 236, 238	Tie Distance	106
Adjustment		Applications	106
Combined adjustment (l, t, c, i)	181	Area	119
Electronic	178	As Built application	111
Mechanical	179	Auto Off	67
Of circular level on tribrach	187	Automatic corrections	245
Of the laser plummet	188		
ALL-in-1	88	B	
Angle & Distance	114	Battery	37, 49
Angle measurement	234	Charging	51
Angle unit	68	First-time use	50
Application		Labelling	233
Angle & Distance	106	Baudrate	73
Area & Volume	106	Beep	65
As Built	106	Bluetooth	
COGO	107	Antenna	247
Hidden Point	107	Output power	247
Layout	106	Safety directions	230
Layout Line/Arc/Spiral	107		

C

Care	196
Check & Adjust	178
Circular level	186
Cleaning and Drying	199
COGO	128
Collimation axis	15
Combined	181
Communication parameters	72
Communication side cover	
Frequency band	247
Technical data	247
Compensator	37, 64, 239
Compensator index	181
Configuration	60
Construction Data Manager	156
Container contents	21
Contrast	68
Control line	95, 96
Control unit	240
Coordinates	100, 102
Corrections	245

D

Data management	146
Data output	73
Data transfer	156
Databits	74
Date	71
Delete	154
Display heater	68
Displayed data	18
Distance measurement	39, 54, 114, 235
Distance unit	70
Documentation	12
How-to Guide	12
User Manual	12
Drives	242

E

EDM	54
Electromagnetic compatibility	228
Electronic adjustment	178
Electronic level	79
Endmark	74
Environmental specifications	244

F		J	
FCC Statement	231	Job	147, 149
Fixpoints	151		
H		K	
Hazards of use	211	Keyboard Builder 100, 200 and 300	30
Height	104	Keyboard Builder 400 and 500	31
Height Transfer	105		
Hidden Point	124	L	
Horizon	63	Language	40
Horizontal angle	15, 38, 79	Laser	
Horizontal circle	15	Beam	192
How to use this manual	12	Classification	217
Hz Collimation	181	Distancer	54
Hz Increment	62	Plummet	47, 79, 242
		Pointer	62
I		Layout	108
Icons	37	Layout Line/Arc/Spiral	137
Instrument	239	Level	45, 79, 239
Components	23	Light	31
Dimensions	241	Limits of use	209
Models	20	Line of sight	15
Temperature	169		
Intended use	207		
Interface	72		

M	
Manual	
Available documentation	13
Description of manuals	12
How to use	12
Validity of user manual	12
Measure	88
Measure & Descriptor	143
Measurements	153
Mechanical adjustment	179
Memory	72, 242
Minimum reading	69
O	
Operating temperature	244
P	
Parity	74
Plumb line	16
Points	151, 153
Ports	240
Power supply	26
Prism	245
CPR105 Flat Prism	58
CPR111 Builder Prism	59
Programs	84, 106
R	
Range	235
Record	67, 88, 242
Reflectors	245
Responsibilities	210
Reticle	17
Reticle illumination	31
Reticule adjustment	194
S	
Safety directions	206
Screen	34
Sector beep	65
Service, tripod	191
Set horizontal angle	79, 81
Setting	76
Setup	
Tripod	42

Shifting Line Startpoint	97	Instrument	169
Software concept	27	Operating	244
Stake out	106	Storage	244
Standing axis	15	USB memory stick	
Station setup	92	Operating	244
Stopbits	74	Storage	244
Storage	197	Tie distance	116
Storage temperature	244	Tilting axis	15
Symbols	3, 38	Time	71
System Info	31, 168	Tracking	62, 161
T		Transport	196
Tab bar	36	Tribrach	187
Technical data	234, 239	Tripod	44, 191
Technical terms	14	Setup	42
Telescope	239	U	
Temperature	244	Unit	240
Battery		USB	
Operating	244	Inserting	52
Storage	244	User interface	30
Builder Arctic			
Operating	244		
Storage	244		

V

V Setting	63
Vertical angle	15, 38, 80
Vertical circle	15
Vertical index	181

W

Weight	241
--------------	-----

Z

Zenith	17, 63
Zenith angle	15

Total Quality Management: Our commitment to total customer satisfaction.



Leica Geosystems AG, Heerbrugg, Switzerland, has been certified as being equipped with a quality system which meets the International Standards of Quality Management and Quality Systems (ISO standard 9001) and Environmental Management Systems (ISO standard 14001).

Ask your local Leica dealer for more information about our TQM program.

Leica Geosystems AG

Heinrich-Wild-Strasse
CH-9435 Heerbrugg
Switzerland
Phone +41 71 727 31 31

www.leica-geosystems.com

- when it has to be **right**

Leica
Geosystems